GE
Industrial Solutions

WORLDWIDE PARTNER

New

EntelliGuard™ L

Power Circuit Breaker

Effective Simplicity

GE imagination at work

2. Features and Benefits
6. Performance Ratings

New line of Air Circuit Breakers

- Evolved from a global platform
- Designed for simplicity
- Manufactured in the European Union



Range and performance

- 400 to 4000A in 2 frame sizes
- Designed to and meets the IEC 60947
- 3P and 4P versions in fixed and withdrawable configurations
- Choice of 50kA or 65kA ratings
- Icu= Ics = Icw for the full range
- Suitable for up to 690V AC
- Designed to be selective



Installation

- Compact and modular build
- No derating up to an ambient of 50°C
- Front-mounted snap-fit accessories
- Accessories and Control voltage indication on the front fascia



Protection

- State-of-the-art micro-processor based trip unit
- TRUE-RMS sensing
- Standard large LCD display
- Touch-pad based programming navigation
- Micro-processor based trip units offering high accuracy
- Standard event logger and diagnostics

Front fascia

1. Installed accessory indicators
2. Electronic trip unit
3. Manual charging handle
4. ON and OFF buttons
5. Contact position indicator ON/OFF
6. Ready to close indicator
7. Mechanical spring charge indication
8. Operation counter
9. Slot to fix breaker key interlock
10. Mechanical position indicator
11. Racking handle pad lock
12. Racking handle
13. Catalogue code



GT- trip unit

Advanced electronic trip unit

1. 1 LCD screen with following menu options:
   - **Setup**
   Allows adjustment of values and settings of all parameters
   - **Meter**
   An ammeter is available on all 3 phases and neutral
   - **Status**
   Breaker in ON / OFF / Trip position
   - **Events**
   Trip history with the fault indication
2. 4 setting and 1 enter key to access trip unit functionality
3. Manual or automatic reset facility

EntelliGuard™

The EntelliGuard is a new line of Air Circuit Breakers developed as a global product meeting IEC standards.
The L version of this breaker is a line of three and four pole devices ranging from 400A to 4000A in two frame sizes with a fault interruption ratings of 50 and 65kA.

The design offer a unique combination of high fault current withstand ratings, short fault interruption times and selectivity.

The device includes a new state-of-the-art highly accurate trip unit that enables the circuit breaker to reliably protect itself and it's environment.

These Power Circuit Breakers are designed to allow multiple interruptions of fault currents and can be used in AC networks with voltages up to 690V.

Selective and fast

EntelliGuard has been designed to offer an uncompromising combination of a high speed interruption at high fault levels. Values of 40 milliseconds or less can be achieved whilst maintaining selectivity.
The circuit breaker is designed to remain closed on a fault as per user settable time value when the fault level lies within the range of short time delay option, and for 15 milliseconds when the fault level attains instantaneous protection range value.
This instantaneous device includes programming that in normal circumstances waits until the downstream breaker trips.



1. Overload protection (LT) with 22 bands
2. Timed short-circuit protection (STD) with 17 bands
3. Selective instantaneous protection (I)
4. Hi-Speed trip (HSIOC)

Uncompromising ... Reliability

EntelliGuard™ has been designed as a modern 'Power Circuit Breaker' without neglecting its GE's heritage of more than 50 years in building Air Circuit Breakers.
The result: a device with a proven electrical and mechanical life span independent of its operation mode. Be it manual, electrical or by means of the installed shunt and/or undervoltage releases.

Hi-Performance: complete line

All power circuit breakers are designed to allow multiple interruptions of fault currents. Here the tested and certified service breaking capacity value is in all cases equal to the stated ultimate breaking capacity.

Hi-Performance: current ratings in enclosures

EntelliGuard™ Air Circuit Breakers have been designed with low power dissipation values and allow relatively high currents at high ambient temperatures.

EN 60947-2 standard

Power Circuit Breaker type		LG04		LG07		LG08		LG10		LG13	
Air Circuit Breaker denomination		S	N	S	N	S	N	S	N	S	N
Poles	Number of	3,4		3,4		3,4		3,4		3,4	
Rated insulation voltage	Ui (Volts)	1000		1000		1000		1000		1000	
Rated impulse withstand voltage	Uimp [Kilovolt]	12		12		12		12		12	
Rated operational voltage Ue	Volts AC	690		690		690		690		690	
Category of use		B		B		B		B		B	
Suitable for use as a isolator	Positive ON & OFF	YES		YES		YES		YES		YES	
Rated current In	A at 50 o C	400		630		800		1000		1250	
Ultimate breaking capacity Icu (kA)	230/240V- 440V AC	50	65	50	65	50	65	50	65	50	65
	500V AC	50	65	50	65	50	65	50	65	50	65
	690V AC	40	40	40	40	40	40	40	40	40	40
Service breaking capacity Ics (kA)	230/240V- 440V AC	50	65	50	65	50	65	50	65	50	65
	500V AC	50	65	50	65	50	65	50	65	50	65
	690V AC	40	40	40	40	40	40	40	40	40	40
Interuption time I < Icw	at 500V AC	60ms		60ms		60ms		60ms		60ms	
Interuption time I >= Icw	at 500V AC	30ms		30ms		30ms		30ms		30ms	
Closing time with closing call		60ms		60ms		60ms		60ms		60ms	
Opening time with closing shunt		40ms		40ms		40ms		40ms		40ms	
Short-circuit withstand Icw (kA)	1 second	50	65	50	65	50	65	50	65	50	65
	3 seconds	30	50	30	50	30	50	30	50	30	50
Short-circuit making current Icm 220-500V AC	kA Peak	105	143	105	143	105	143	105	143	105	143
Mechanical endurance	With maintenance	20000		20000		20000		20000		20000	
	Without maintenance	10000		10000		10000		10000		10000	
Electrical endurance (CO operations at 440V AC)	Without maintenance	5000		5000		5000		5000		5000	

Electronic Trip Unit

GT -L type with Ammeter	LT, ST, I, GF	Possible	Possible	Possible	Possible	Possible

EN 60947-3 standard

Power Circuit Breaker type		LJ04	LJ07	LJ08	LJ10	LJ13
		Non Auto	Non Auto	Non Auto	Non Auto	Non Auto
Isolator denomination		R	R	R	R	R
Poles	Number of	3,4	3,4	3,4	3,4	3,4
Rated insulation voltage	Ui (Volts)	1000	1000	1000	1000	1000
Rated impulse withstand voltage	Uimp [Kilovolt]	12	12	12	12	12
Suitable for use as a isolator	Positive ON & OFF	YES	YES	YES	YES	YES
Rated operational voltage Ue	Volts AC	690	690	690	690	690
Rated current In	A at 50 o C	400	630	800	1000	1250
Short-circuit withstand Icw (kA)	1 second	42	42	42	42	42
	3 seconds	30	30	30	30	30
Short-circuit making current Icm 220-500V AC	kA Peak	88,2	88,2	88,2	88,2	88,2
Mechanical endurance	With maintenance	20000	20000	20000	20000	20000
	Without maintenance	10000	10000	10000	10000	10000
Electrical endurance (CO operations at 440V AC)	Without maintenance	5000	5000	5000	5000	5000

Installation

Fixed pattern						
Dimensions in mm	Height	438	438	438	438	438
	Width 3pole	338	338	338	338	338
	Width 4pole	438	438	438	438	438
	Depth[1]	328	328	328	328	328
Available connection modes	Rear Horizontal	X	X	X	X	X
	Rear Vertical	X	X	X	X	X
	Front	X	X	X	X	X
Weights in kg	3 pole	42	42	42	42	42
	4 pole	50	50	50	50	50
Draw-out pattern						
Dimensions in mm	Height	439	439	439	439	439
	Width 3pole	331	331	331	331	331
	Width 4pole	431	431	431	431	431
	Depth[2]	432	432	432	432	432
Available connection modes	Rear Horizontal	X	X	X	X	X
	Rear Unviersal[2]	X	X	X	X	X
	Front	X	X	X	X	X
Weights in kg	3 pole	60	60	60	60	60
	4 pole	72	72	72	72	72

(1) With horizontal rear connections: Indicated depth value is the required panel dimension.
(2) T stubs can be rotated and used for both vertical & horizontal rear connection.
(3) The 4000A rating is only available with rear vertical connections.

	LG16		LG20				LG25				LG32		LG40	
	S	N	S	N	C	D	S	N	C	D	C	D	C	D
	3,4		3,4				3,4				3,4		3,4	
	1000		1000				1000				1000		1000	
	12		12				12				12		12	
	690		690				690				690		690	
	B		B				B				B		B	
	YES		YES				YES				YES		YES	
	1600		2000				2500				3200		4000	
	50	65	50	65	50	65	50	65	50	65	50	65	50	65
	50	65	50	65	50	65	50	65	50	65	50	65	50	65
	40	40	40	40	50	50	40	40	50	50	50	40	50	50
	50	65	50	65	50	65	50	65	50	65	50	65	50	65
	50	65	50	65	50	65	50	65	50	65	50	65	50	65
	40	40	40	40	40	40	40	40	40	40	40	40	40	40
	60ms		60ms		60ms		60ms		60ms		60ms		60ms	
	30ms		30ms		30ms		30ms		30ms		30ms		30ms	
	60ms		60ms		60ms		60ms		60ms		60ms		60ms	
	40ms		40ms		40ms		40ms		40ms		40ms		40ms	
	50	65	50	65	50	65	50	65	50	65	50	65	50	65
	30	50	30	50	50	50	30	50	50	50	50	50	50	50
	105	143	105	143	105	143	105	143	105	143	110	143	110	143
	20000		20000				20000				20000		20000	
	10000		10000				10000				10000		10000	
	5000		5000				5000				5000		5000	

	Possible	Possible		Possible		Possible	Possible

	LJ16	LJ20		LJ25		LJ32	LJ40
	Non Auto	Non Auto		Non Auto		Non Auto	Non Auto
	R	R	C	R	C	C	C
	3,4	3,4	3,4	3,4	3,4	3,4	3,4
	1000	1000	1000	1000	1000	1000	1000
	12	12	12	12	12	12	12
	YES	YES	YES	YES	YES	YES	YES
	690	690	690	690	690	690	690
	1600	2000		2500		3200	4000
	42	42	50	42	50	50	50
	30	30	50	30	50	50	50
	88,2	88,2	105	88,2	105	105	105
	20000	20000		20000		20000	20000
	10000	10000		10000		10000	10000
	5000	5000		5000		5000	5000

	438	438	438	438	438	438	438
	338	338	432	338	432	432	432
	438	438	562	438	562	562	562
	328	328	328	328	328	328	393 [3]
	X	X	X	X	X	X	---
	X	X	X	X	X	X	Rear Vertical [3]
	X	X	X	X	X	X	X
	42	52	63	58	63	63	69
	50	65	76	73	76	76	84
	439	439	439	439	439	439	439
	331	331	421	421	421	421	421
	431	431	551	551	551	551	551
	432	432	432	432	432	432	534
	X	X	X	X	X	X	---
	X	X	X	X	X	X	X
	X	X	X	X	X	X	Rear Vertical [3]
	60	72	105	74	105	105	120
	72	88	130	91	130	130	145

Notes

Power Circuit Breakers

A.2 EntelliGuard L: How to order in eight steps

A.4 Basic breakers executed in a fixed mounting pattern

A.6 Isolators or Non Automatic breakers in a fixed mounting pattern

A.5-A.7 Non standard connection options for fixed breakers & isolators

A.4 Basic breakers: Drawout breakers; Moving portion only

A.6 Isolators or Non Automatic breakers: Drawout breakers; Moving portion only

A.5-A.7 Factory mounted cassettes for drawout breakers

A.8 Factory mounted Trip Units

A.9-A.10 Factory mounted internal accessories.
(Motor Operators Coils, Auxiliary Contacts Releases etc.)

A.11 Field mountable internal accessories
(Motor Operators Coils, Auxiliary Contacts Releases etc.)

A.12 Cassettes for Drawout breakers

A.13-A,14 Other accessories

A.14 Spare parts

A.16-A.17 Alternative Ordering Method and 18-digit Catalogue Number for breakers

A.18 Alternative Ordering Method and 12-digit Catalogue Number for cassettes

A.19 Overview : Factory mounted available standard breakers,
Cassettes & Trip Units

A.20 Overview : Factory and/or Field mountable accessories & spares

How to order

Step 1	Step 2		Step 3		Step 4
Choose Current rating	Choose required Interruption rating		Define if a Breaker or Isolator is needed. Proceed to establish the first 5 digits of the catalogue number as indicated here		Select the required product A - Breaker or Isolator *In Fixed Pattern* B - Breaker or Isolator *As Drawout, Moving Portion* C - Cassette for Draw-out *Breaker or Isolator*

In	Icu = Ics	Icw	Envelope	Standard	
	≤ 440V AC			Breaker	Isolator[1]
400A	50kA	50kA	1	LG04S	
	65kA	65kA	1	LG04N	
		42kA	1		LJ04R
630A	50kA	50kA	1	LG07S	
	65kA	65kA	1	LG07N	
		42kA	1		LJ07R
800A	50kA	50kA	1	LG08S	
	65kA	65kA	1	LG08N	
		42kA	1		LJ08R
1000A	50kA	50kA	1	LG10S	
	65kA	65kA	1	LG10N	
		42kA	1		LJ10R
1250A	50kA	50kA	1	LG13S	
	65kA	65kA	1	LG13N	
		42kA	1		LJ13R
1600A	50kA	50kA	1	LG16S	
	65kA	65kA	1	LG16N	
		42kA	1		LJ16R
2000A	50kA	50kA	1	LG20S	
	65kA	65kA	1	LG20N	
		42kA	1		LJ20R
	50kA	50kA	2	LG20C	
	65kA	65kA	2	LG20D	
		50kA	2		LJ20C
2500A	50kA	50kA	1	LG25S	
	65kA	65kA	1	LG25N	
		42kA	1		LJ25R
	50kA	50kA	2	LG25C	
	65kA	65kA	2	LG25D	
		50kA	2		LJ25C
3200A	50kA	50kA	2	LG32C	
	65kA	65kA	2	LG32D	
		50kA	2		LJ32C
4000A	50kA	50kA	2	LG40C	
	65kA	65kA	2	LG40D	
		50kA	2		LJ40C

Defines the 6th digit on catalogue number

- **4** = Breaker / Isolator In Fixed Pattern 3 pole
- **6** = Breaker / Isolator In Fixed Pattern 4 pole[1]
- **1** = Breaker / Isolator Moving Portion Only 3 pole
- **3** = Breaker / Isolator Moving Portion Only 4 pole[1]
- **2** = Cassette for Drawout Pattern = Fixed Portion Only 3 pole
- **5** = Cassette for Drawout Pattern = Fixed Portion Only 4 pole[1]

(1) 4 pole Neutral left

Examples

Breaker 4P 1600A - Draw-out portion only
- Icu=Ics=Icw=65kA: **LG16N3**

Breaker 3P 2500A Fixed pattern - Horizontal rear connections
- Icu=Ics=Icw=50kA: **LG25S6**

in eight simple steps

Step 5

Finalize the basic catalogue number see catalogue pages:
A 4-A.6 - Fixed Pattern
A 4-A.6 - Drawout Portion
A.5-A.7 - Connections fixed pat.
A 5-A.7 - Cassettes, drawout

Completing the basic catalogue number

No addition
Breaker in fixed pattern equipped with RearConnection (Horizontal**), a set of 3NO/3NC aux. Contacts is included

Other options include Rear(Vertcal) and Front (Flat) connections

See page A 6 to order Field mountable Adaptation Kits
Field mountable

See pages A.4 & A.6

No addition
Indicates Breaker / Isolator Moving Portion Only has set of 3NO/3NC aux. Contacts included

See pages A.4 & A.6

U
= Cassette withUniversal 'T stabs' suited for use as Horizontal or Vertical rear connections

H
= Cassette with Horizontal Rear Connections

V
= Cassette with Vertical Rear Connections
Vertical Rear Connections

F
= Cassette with Front Flat connections

Safety Shutters always Supplied with Cassette

See page A.5 & A.7

Step 6

Basic catalogue number is a manually operated device
If a Motor Operated device is requested?
Please order
Motor and closing coils as Indicated here

Add catalogue number (s)

If chosen device is a Breaker or Isolator

Envelope 1
See page A.9
Order a Motor Envelope 1 and 1 Closing Coil
Based on voltage Requirements and specifications

If chosen device is a Breaker or Isolator

Envelope 2
See page A.9
Order a Motor Envelope 2 and 1 Closing Coil
Based on voltage Requirements and specifications

Step 7

If universal internal accessories are needed?
Options
UVR or SHT release (s)
Auxiliary contacts
Alarm & signal contacts

Add catalogue number (s)

If chosen device is a Breaker or Isolator
See page A.9

To add 1 SHT and/or 1 UVR release or two SHT releases.

If chosen device is a Breaker or Isolator
See page A.9

To extend on the installed 3 NO + 3NC contacts
Maximum of 4 possible

If chosen device is a Breaker or Isolator
See page A.9

To add Bell Alarm and/or Ready to close contact

If chosen device is a Cassette
See page A.9

If chosen device is a Cassette
See page A.9

Step 8

Full catalogue number defines a Breaker without trip unit.
(Isolators do not need trip units)
For all Breakers ADD
Trip Unit

Add catalogue number (s)

If chosen device is a Breaker
See page A.8

Add one of Four Basic Trip units types

Offering

An Extremely Large setting range covering Overload, Delayed and Instantaneous Short Circuit Protection and or Groundfault

- Or -

A 2nd ordering method can be used in which the fully configured breaker or cassette is defined in one character string, This string comprises 18 digits when used for the breaker and 12 for when used for the cassette.
This global ordering code is referred to within GE as the :
Catalogue Number
It can be defined with stand alone and freely available GE software , is used on all relevant ordering documents and printed on each EntelliGuard breaker front facia. An explanation of this code and it's use can be found on page A.28 of this catalogue.

When ordering with the method indicated here our CRC department will define and confirm the mentioned individual ***Catalogue Number***.

Devices ordered here are supplied factory fitted.

Remark : For Other Field Mountable Accessories see page A.11, A.12 & A.13

Basic breakers executed in a fixed mounting pattern

- With Horizontal Rear Connection. (For other options, please refer to page A.7)
- With auxiliary contact block equipped with 3 NO and 3 NC contacts
- Basic breaker MUST be equipped with a Trip Unit. (Please refer to page A.8 for options)



		3 pole		4 pole[1]	
	Rating (A)	Cat. No.	Ref. No.	Cat. No.	Ref. No.
S type Icu = Ics = Icw 50kA	400	LG04S4	**444066**	LG04S6	**444100**
	630	LG07S4	**444067**	LG07S6	**444101**
	800	LG08S4	**444068**	LG08S6	**444102**
	1000	LG10S4	**444069**	LG10S6	**444103**
	1250	LG13S4	**444070**	LG13S6	**444104**
	1600	LG16S4	**444071**	LG16S6	**444105**
	2000	LG20S4	**444072**	LG20S6	**444106**
	2500	LG25S4	**444073**	LG25S6	**444107**
N type Icu = Ics = Icw 65kA	400	LG04N4	**444078**	LG04N6	**444112**
	630	LG07N4	**444079**	LG07N6	**444113**
	800	LG08N4	**444080**	LG08N6	**444114**
	1000	LG10N4	**444081**	LG10N6	**444115**
	1250	LG13N4	**444082**	LG13N6	**444116**
	1600	LG16N4	**444083**	LG16N6	**444117**
	2000	LG20N4	**444084**	LG20N6	**444118**
	2500	LG25N4	**444085**	LG25N6	**444119**
C type Icu = Ics =Icw 50kA	2000	LG20C4	**444074**	LG20C6	**444108**
	2500	LG25C4	**444075**	LG25C6	**444109**
	3200	LG32C4	**444076**	LG32C6	**444110**
	4000	LG40C4	**444077**	LG40C6	**444111**
D type Icu = Ics = Icw 65kA	2000	LG20D4	**444086**	LG20D6	**444120**
	2500	LG25D4	**444087**	LG25D6	**444121**
	3200	LG32D4	**444088**	LG32D6	**444122**
	4000	LG40D4	**444089**	LG40D6	**444123**

Basic breakers: Drawout Breakers; Moving portion only

- With auxiliary contact block equipped with 3 NO and 3 NC contacts
- Basic Breaker MUST be equipped with a Trip Unit. (Please refer to page A.8 for options)
- A cassette is needed, please refer to page A.5 for options



		3 pole		4 pole[1]	
	Rating (A)	Cat. No.	Ref. No.	Cat. No.	Ref. No.
S type Icu = Ics = Icw 50kA	400	LG04S1	**444000**	LG04S3	**444033**
	630	LG07S1	**444001**	LG07S3	**444034**
	800	LG08S1	**444002**	LG08S3	**444035**
	1000	LG10S1	**444003**	LG10S3	**444036**
	1250	LG13S1	**444004**	LG13S3	**444037**
	1600	LG16S1	**444005**	LG16S3	**444038**
	2000	LG20S1	**444006**	LG20S3	**444039**
	2500	LG25S1	**444007**	LG25S3	**444040**
N type Icu = Ics = Icw 65kA	400	LG04N1	**444012**	LG04N3	**444045**
	630	LG07N1	**444013**	LG07N3	**444046**
	800	LG08N1	**444014**	LG08N3	**444047**
	1000	LG10N1	**444015**	LG10N3	**444048**
	1250	LG13N1	**444016**	LG13N3	**444049**
	1600	LG16N1	**444017**	LG16N3	**444050**
	2000	LG20N1	**444018**	LG20N3	**444051**
	2500	LG25N1	**444019**	LG25N3	**444052**
C type Icu = Ics =Icw 50kA	2000	LG20C1	**444008**	LG20C3	**444041**
	2500	LG25C1	**444009**	LG25C3	**444042**
	3200	LG32C1	**444010**	LG32C3	**444043**
	4000	LG40C1	**444011**	LG40C3	**444044**
D type Icu = Ics = Icw 65kA	2000	LG20D1	**444020**	LG20D3	**444053**
	2500	LG25D1	**444021**	LG25D3	**444054**
	3200	LG32D1	**444022**	LG32D3	**444055**
	4000	LG40D1	**444023**	LG40D3	**444056**

(1) 4th pole on Left, Trip Unit configurable at 0, 50 or 100% of phase rating

Termination sets for Breakers & Isolators in fixed pattern

To modify standard connection (horizontal rear) to:
- Vertical rear
- Front flat connection

Sets containing terminals and hardware for the line & load side of the breaker

Vertical rear connections



Rating (A)	Suited for use with EntelliGuard -L types	3 pole Cat. No.	3 pole Ref. No.	4 pole Cat. No.	4 pole Ref. No.
Terminations for envelope 1					
400 - 1600A	LG version S	L16S4RVI	**444441**	L16S6RVI	**444443**
2000 - 2500A	LG version S	L25N4RVI	**444445**	L25N6RVI	**444446**
400 - 2500A	LG & LJ versions N & R				
Terminations for envelope 2					
2000 - 3200A	LG & LJ versions C & D	G32M4RVI	**408070**	G32M6RVI	**408071**
4000A	LG & LJ versions C & D	G40M4RVI	**408072**	G40M6RVI	**408074**

Front access connections

Terminations for envelope 1					
400 - 1600A	LG version S	L16S4FFI	**444440**	L16S6FFI	**444442**
2000 - 2500A	LG version S	L25N4FFI	**444444**	L25N6FFI	**444446**
400 - 2500A	LG & LJ versions N & R				
Terminations for envelope 2					
2000 - 3200A	LG & LJ versions C & D	G32M4FFI	**408066**	G32M6FFI	**408068**
4000A	LG & LJ versions C & D	G40M4FFI	**408067**	G40M6FFI	**408069**



Cassettes for use with Breakers & Isolators in Drawout pattern

References apply for cassettes supplied in one packaging with Breakers or Isolators
(For separate cassettes see page A.12)
- With connection modes as indicated in left column
- Each cassette is supplied with safety shutters

Horizontal Rear Connections



Rating (A)	Suited for use with EntelliGuard -L types	3 pole Cat. No.	3 pole Ref. No.	4 pole Cat. No.	4 pole Ref. No.
Cassette for envelope 1					
400 - 1250A	LG version S	LG13S2HM	**444272**	LG13S5HM	**444275**
1600A	LG version S	LG16S2HM	**444278**	LG16S5HM	**444281**
2000A	LG version S	LG20N2HM	**444284**	LG20N5HM	**444287**
400 - 2000A	LG & LJ versions N & R				
Cassette for envelope 2					
2000 - 3200A	LG & LJ versions C & D	LG32D2HM	**444289**	LG32D5HM	**444291**
Each cassette is supplied with connection pads for Horizontal connections.					

Universal rear Connections



Cassette for envelope 1					
400 - 1250A	LG version S	LG13S2UM	**444271**	LG13S5UM	**444274**
1600A	LG version S	LG16S2UM	**444277**	LG16S5UM	**444280**
2000 - 2500A	LG version S	LG25N2UM	**444283**	LG25N5UM	**444286**
400 - 2500A	LG & LJ versions N & R				
Cassette for envelope 2					
2000 - 3200A	LG & LJ versions C & D	LG32D2UM	**444288**	LG32D5UM	**444290**
Each cassette is supplied with connection pads that be rotated and used for Vertical or Horizontal connections.					

Vertical access Connections



Cassettes for Envelope 2					
4000A	LG & LJ versions C & D	LG40D2VM	**444292**	LG40D5VM	**444293**
Each cassette is supplied with Vertical connections.					

Front Connections

Cassettes for Envelope 1					
400 - 1250A	LG version S	LG13S2FM	**444270**	LG13S5FM	**444273**
1600A	LG version S	LG16S2FM	**444276**	LG16S5FM	**444279**
2000 - 2500A	LG version S	LG25N2FM	**444282**	LG25N5FM	**444285**
400 - 2500A	LG & LJ versions N & R				
Each cassette is supplied with connection pads for front connections.					

Isolators or Non Automatic breakers executed in a fixed mounting pattern

- With horizontal rear connection. (For other options, please refer to page A.7)
- With auxiliary contact block equipped with 3 NO and 3 NC contacts

		3 pole		4 pole[1]	
	Rating (A)	Cat. No.	Ref. No.	Cat. No.	Ref. No.
R type Icw=42kA	400	LJ04R4	**444161**	LJ04R6	**444173**
	630	LJ07R4	**444162**	LJ07R6	**444174**
	800	LJ08R4	**444163**	LJ08R6	**444175**
	1000	LJ10R4	**444164**	LJ10R6	**444176**
	1250	LJ13R4	**444165**	LJ13R6	**444177**
	1600	LJ16R4	**444166**	LJ16R6	**444178**
	2000	LJ20R4	**444167**	LJ20R6	**444179**
	2500	LJ25R4	**444168**	LJ25R6	**444180**
C type Icw=50kA	2000	LJ20C4	**444169**	LJ20C6	**444181**
	2500	LJ25C4	**444170**	LJ25C6	**444182**
	3200	LJ32C4	**444171**	LJ32C6	**444183**
	4000	LJ40C4	**444172**	LJ40C6	**444184**

Isolators or Non Automatic breakers: Drawout Breakers; Moving portion only

- With auxiliary contact block equipped with 3 NO and 3 NC contacts
- A cassette is needed, please refer to page A.7 for options

		3 pole		4 pole[1]	
	Rating (A)	Cat. No.	Ref. No.	Cat. No.	Ref. No.
R type Icw=42kA	400	LJ04R1	**444135**	LJ04R3	**444147**
	630	LJ07R1	**444136**	LJ07R3	**444148**
	800	LJ08R1	**444137**	LJ08R3	**444149**
	1000	LJ10R1	**444138**	LJ10R3	**444150**
	1250	LJ13R1	**444139**	LJ13R3	**444151**
	1600	LJ16R1	**444140**	LJ16R3	**444152**
	2000	LJ20R1	**444141**	LJ20R3	**444153**
	2500	LJ25R1	**444142**	LJ25R3	**444154**
C type Icw=50kA	2000	LJ20C1	**444143**	LJ20C3	**444155**
	2500	LJ25C1	**444144**	LJ25C3	**444156**
	3200	LJ32C1	**444145**	LJ32C3	**444157**
	4000	LJ40C1	**444146**	LJ40C3	**444158**

(1) 4th pole on Left, Trip Unit Configurable at 0.50 or 100% of phase rating

Termination sets for Breakers & Isolators in fixed pattern

To modify standard connection (horizontal rear) to:
- Vertical rear
- Front flat connection

Sets containing terminals and hardware for the line & load side of the breaker

Vertical rear connections



Rating (A)	Suited for use with EntelliGuard L types	3 pole Cat. No.	3 pole Ref. No.	4 pole Cat. No.	4 pole Ref. No.
Terminations for envelope 1					
400 - 1600A	LG version S	L16S4RVI	**444441**	L16S6RVI	**444443**
2000 - 2500A	LG version S	L25N4RVI	**444445**	L25N6RVI	**444446**
400 - 2500A	LG & LJ versions N & R				
Terminations for envelope 2					
2000 - 3200A	LG & LJ versions C & D	G32M4RVI	**408070**	G32M6RVI	**408071**
4000A	LG & LJ versions C & D	G40M4RVI	**408072**	G40M6RVI	**408074**

Front access connections

Terminations for envelope 1					
400 - 1600A	LG version S	L16S4FFI	**444440**	L16S6FFI	**444442**
2000 - 2500A	LG version S	L25N4FFI	**444444**	L25N6FFI	**444446**
400 - 2500A	LG & LJ versions N & R				
Terminations for envelope 2					
2000 - 3200A	LG & LJ versions C & D	G32M4FFI	**408066**	G32M6FFI	**408068**
4000A	LG & LJ versions C & D	G40M4FFI	**408067**	G40M6FFI	**408069**



Cassettes for use with Breakers & Isolators in Drawout pattern

References apply for cassettes supplied in one packaging with breakers or isolators
(For separate cassettes see page A.12)
- With connection modes as indicated in left column.
- Each cassette is supplied with safety shutters

Horizontal rear connections



Rating (A)	Suited for use with EntelliGuard L types	3 pole Cat. No.	3 pole Ref. No.	4 pole Cat. No.	4 pole Ref. No.
Cassette for envelope 1					
400 - 1250A	LG version S	LG13S2HM	**444272**	LG13S5HM	**444275**
1600A	LG version S	LG16S2HM	**444278**	LG16S5HM	**444281**
2000A	LG version S	LG20N2HM	**444284**	LG20N5HM	**444287**
400 - 2000A	LG & LJ versions N & R				
Cassette for envelope 2					
2000 - 3200A	LG & LJ versions C & D	LG32D2HM	**444289**	LG32D5HM	**444291**
Each cassette is supplied with connection pads for Horizontal connections.					

Universal rear connections



Cassette for envelope 1					
400 - 1250A	LG version S	LG13S2UM	**444271**	LG13S5UM	**444274**
1600A	LG version S	LG16S2UM	**444277**	LG16S5UM	**444280**
2000 - 2500A	LG version S	LG25N2UM	**444283**	LG25N5UM	**444286**
400 - 2500A	LG & LJ versions N & R				
Cassette for envelope 2					
2000 - 3200A	LG & LJ versions C & D	LG32D2UM	**444288**	LG32D5UM	**444290**
Each cassette is supplied with connection pads that be rotated and used for Vertical or Horizontal connections.					

Vertical access connections

Cassettes for Envelope 2					
4000A	LG & LJ versions C & D	LG40D2VM	**444292**	LG40D5VM	**444293**
Each cassette is supplied with Vertical connections.					

Front connections

Cassettes for Envelope 1					
400 - 1250A	LG version S	LG13S2FM	**444270**	LG13S5FM	**444273**
1600A	LG version S	LG16S2FM	**444276**	LG16S5FM	**444279**
2000 - 2500A	LG version S	LG25N2FM	**444282**	LG25N5FM	**444285**
400 - 2500A	LG & LJ versions N & R				
Each cassette is supplied with connection pads for front connections.					

GT type Trip Units for Power Circuit Breakers

Factory Mounted Trip Units

GT- L

Basic functionality	Designation	Cat. No.	Ref. No.
	**GT-L Trip Unit with:** LT-C 0.4 -1 x In = Ir tr (22 C type curves) SD I2T ON or OFF tSD (90ms to 1 sec.)	LTG00K1XXSF	**444260**
	**GT-L Trip Unit with:** LT-C 0.4 -1 x In = Ir tr (22 C type curves) SD I2T ON or OFF tSD (90ms to 1 sec.) GF I2T ON or OFF tg (100 ms to 0.9 sec))	LTG00K2XXSF	**444261**
	**GT-L Trip Unit with:** LT-C 0.4 -1 x In = Ir tr (22 C type curves) SD I2T ON or OFF tSD (90ms to 1 sec.) Ii	LTG00K9XXSF	**444262**
	**GT-L Trip Unit with:** LT-C 0.4 -1 x In = Ir tr (22 C type curves) SD I2T ON or OFF tSD (90ms to 1 sec.) GF I2T ON or OFF tg (100 ms to 0.9 sec)) Ii	LTG00K3XXS	**444263**

Rogowski coils

For groundfault protection with 3pole breaker in 4 wire networks
For use as spares

Sensors

Rating	Envelope 1 Cat. No.	Envelope 1 Ref. No.	Envelope 2 Cat. No.	Envelope 2 Ref. No.
400A	L104NRC	**444420**		
630A	L106NRC	**444421**		
800A	L108NRC	**444422**		
1000A	L110NRC	**444423**		
1250A	L113NRC	**444424**		
1600A	L116NRC	**444425**		
2000A	L120NRC	**444426**	L220NRC	**444427**
2500A	L125NRC	**444428**	L225NRC	**444429**
3200A			L232NRC	**444430**
4000A			L240NRC	**444432**

Internal Accessories - Factory mounted

For field mounted variants see page A.11

Motor Operators & Closing Coils (1)



	Motor Operator Envelope 1		Motor Operator Envelope 2		Closing Coil	
	Cat. No.	Ref. No.	Cat. No.	Ref. No.	Cat. No.	Ref. No.
24-30V DC	LM01024D	**444190**	GM01024D	**407700**	GCCN024D	**407861**
110-130V DC	LM01110D	**444191**	GM01110D	**407706**	GCCN120	**407867**
220V DC	LM01220D	**444192**	GM01220D	**407720**	GCCN240	**407869**
110-130V AC	LM01120A	**444193**	GM01120A	**407712**	GCCN120	**407867**
220-240V AC	LM01240A	**444194**	GM01240A	**407714**	GCCN240	**407869**

Releases

	Undervoltage		Shunt	
2V DC	GUVT024D	**407795**	GSTR024D	**407770**
48V DC; 40-48V AC	GUVT048	**407797**	GSTR048	**407772**
110-130V AC-DC	GUVT120	**407801**	GSTR120	**407776**
220-240V AC-DC	GUVT240	**407803**	GSTR240	**407778**
380- 415V AC	GUVT400A	**407807**	GSTR400A	**407782**

Auxiliary Contacts

Power Rated 3NO & 3NC	LAS3	**444205**
(Delivered as standard option in all EntelliGuard L breakers & Isolators)		
Power Rated 4NO & 4NC	LAS4	**444206**

Indication Contacts

Bell Alarm Contact	LBAT1	**444207**
1 Change over contact		
Ready to Closes Contact	GRTC1	**407897**
1 NO contact		

Position Indication Contacts Cassette

1 NO + 1 NC per position	LCPS1	**444230**
2 NO + 2 NC per position	LCPS2	**444232**

Locking Mechanisms (2)

	Ronis		Profalux		Castell 19mm type	
Mounted on Breaker	LBRON	**444212**	LBPRO	**444211**	LBCA9	**444214**
One Lock can be mounted						
Mounted on cassette	LCRON	**444216**	LCPRO	**444215**		
One Lock can be mounted						

Operation Counter

On Front Fascia of Breaker		
Counter; number of Operations	GMCN	**408035**

(1) Supplied with spring charged contact
(2) See page A.11 for locks

Internal Accessories - Factory mounted

For field mounted variants see page A.11

Mounted Interlocks for Cables [1]



Interlock scheme				Fixed pattern		Draw-out	
Type	Brk. 1	Brk. 2	Brk. 3	Cat. No.	Ref. No.	Cat. No.	Ref. No.
A	OFF	OFF		For each Breaker		For each Breaker	
	ON	OFF		LI2FAD	**444221**	LI2WAD	**444222**
	OFF	ON					
B	OFF	OFF	OFF	For each Breaker		For each Breaker	
	ON	OFF	OFF	LI3FB	**444223**	LI3WB	**444224**
	OFF	ON	OFF				
	OFF	OFF	ON				
C	OFF	OFF	OFF				
	ON	OFF	OFF				
	OFF	OFF	ON	For each Breaker		For each Breaker	
	OFF	ON	OFF	LI3FC	**444225**	LI3WC	**444226**
	ON	ON	OFF				
	OFF	ON	ON				
	ON	OFF	ON				
D	OFF	OFF	OFF	For Brk.1 & 3		For Brk.1 & 3	
	ON	OFF	OFF	LI2FAD	**444221**	LI2WAD	**444222**
	OFF	OFF	ON				
	ON	OFF	ON	For Brk. 2		For Brk. 2	
	OFF	ON	OFF	LI3FDT	**444227**	LI3WDT	**444228**

Internal Accessories

Maximum amount of installable internal accessories

Motor Operator type 1 or 2	Closing Coil	Undervoltage Release[3]	Shunt Release	Auxiliary contacts NO+NC	Bell Alarm contacts	Ready to Close indication	Spring Charged indication	Caraiage Indication Contacts (per Pos.)	Locking Mechanism Breaker	Locking Mechanism Cassette
1	1	1	1	4	1	0	1	2	1	1
1	0	2	1	4	1	0	1	2	1	1
1	1	1	1	4	1	1	0	2	1	1
1	0	2	1	4	1	1	0	2	1	1

(1) These kits are only available FACTORY MOUNTED: On a drawout breaker or isolator the that mechanisms are mounted on the breaker cassette need to be ordered in combination with a breaker and mounted Cassette. For the associated, separately available cables see page A.11.
(2) TDM module (Time delay module) is mounted externally to the breaker.

Internal Accessories - Field mountable

For factory mounted variants see page A.9

Motor operators & closing Coils [1]



	Motor operator envelope 1		Motor operator envelope 2		Closing coil	
	Cat. No.	**Ref. No.**	**Cat. No.**	**Ref. No.**	**Cat. No.**	**Ref. No.**
24-30V DC	LM01024DR	**444195**	GM01024DR	**407701**	GCCN024DR	**407860**
110-130V DC	LM01110DR	**444196**	GM01110DR	**407707**	GCCN120R	**407866**
220V DC	LM01220DR	**444197**	GM01220DR	**407721**	GCCN240R	**407868**
110-130V AC	LM01120AR	**444198**	GM01120AR	**407713**	GCCN120R	**407866**
220-240V AC	LM01240AR	**444199**	GM01240AR	**407715**	GCCN240R	**407868**

Releases

	Undervoltage		Shunt	
2V DC	GSTR024DR	**407796**	GSTR024DR	**407771**
48V DC; 40-48V AC	GSTR048R	**407798**	GSTR048R	**407773**
110-130V AC-DC	GSTR120R	**407802**	GSTR120R	**407777**
220-240V AC-DC	GSTR240R	**407804**	GSTR240R	**407779**
380- 415V AC	GSTR400AR	**407808**	GSTR400AR	**407783**

Auxiliary contacts

Power rated 3NO & 3NC	LAS3R	**444208**
(Delivered as standard option in all EntelliGuard L breakers & Isolators)		
Power Rated 4NO & 4NC	LAS4R	**444209**

Indication contacts

Bell alarm contact	LBAT1R	**444210**
1 Change over contact		

Position indication contacts cassette



1 NO + 1 NC per position	LCPS1R	**444231**
2 NO + 2 NC per position	LCPS2R	**444233**

Locks with random key nr.



	Ronis		Profalux	
	Cat. No.	**Ref. No.**	**Cat. No.**	**Ref. No.**
Ronis 1104 B Lock[2]	GRON	**407985**		
Profalux B204Y Lock[2]			GPRO	**407986**

Operation counter

On Front Fascia of breaker		
Counter; number of Operations	GMCNR	**408033**

(1) Supplied with spring charged contact
(2) See page A.9 for lock mechanisms



Cassettes for use with Breakers & Isolators in Draw-out pattern

- References apply for separately suppllied cassettes for breakers or isolators
  (For cassettes supplied with breaker see page A.5)
- With connection modes as indicated in left column
- Each cassette is supplied with safety shutters

Cassettes for Draw-out Pattern; fixed portion only



Horizontal rear connections

Rating (A)	Suited for use with EntelliGuard™ -L types	3 pole Cat. No.	3 pole Ref. No.	4 pole Cat. No.	4 pole Ref. No.
Cassettes for Envelope 1					
400 - 1250A	LG version S	LG13S2HR	**444302**	LG13S5HR	**444305**
1600A	LG version S	LG16S2HR	**444308**	LG16S5HR	**444311**
2000A	LG version S	LG20N2HR	**444314**	LG20N5HR	**444317**
400 - 2500A	LG & LJ versions N & R				
Cassettes for Envelope 2					
2000 - 3200A	LG & LJ versions C & D	LG32D2HR	**444319**	LG32D5UR	**444320**

Remark: Each cassette is supplied with connection pads for Horizontal connections.



Universal rear connections

Cassettes for Envelope 1					
400 - 1250A	LG version S	LG13N2UR	**444301**	LG13N5UR	**444304**
1600A	LG version S	LG16N2UR	**444307**	LG16N5UR	**444310**
2500A	LG version S	LG25N2UR	**444313**	LG25N5UR	**444316**
400 - 2500A	LG & LJ versions N & R				
Cassettes for Envelope 2					
2000 - 3200A	LG & LJ versions C & D	LG32D2UR	**444318**	LG32D5HR	**444321**

Remark: Each cassette is supplied with connection pads that be rotated and used for Vertical or Horizontal connections.



Vertical access connections

Cassettes for Envelope 2					
4000A	LG & LJ versions C & D	LG40D2VR	**444322**	LG40D5VR	**444323**

Remark: Each cassette is supplied with Vertical connections.

Front connections

Cassettes for Envelope 1					
400 - 1250A	LG version S	LG13S2FR	**444300**	LG13S5FR	**444303**
1600A	LG version S	LG16S2FR	**444306**	LG16S5FR	**444309**
2000 - 2500A	LG version S	LG25N2FR	**444312**	LG25N5FR	**444315**
400 - 2500A	LG & LJ versions N & R				

Remark: Each cassette is supplied with connection pads for front connections.

Casssette top covers	*Insulating top covers*				
Cassette for Envelope 1		L1CTC1	**444450**	L1CTC3	**444451**
Cassette for Envelope 2		L2CTC1	**444452**	L2CTC3	**444453**

Accessories - Other

Field mountable cables for interlocking of breakers (1)

Interlock Type	Interlock scheme: No. of Cables Needed		Cat. No.	Ref. No.
A	1 cable per breaker, choose length as indicated			
B	1 cable per breaker, choose length as indicated	Cable length 1 metre	GCB1	**407990**
		Cable length 1,6 metre	GCB2	**407991**
C	1 cable per breaker, choose length as indicated	Cable length 2 metre	GCB3	**407992**
		Cable length 2,5 metre	GCB4	**407993**
D	Breaker's 1 and 3: 1 cable per breaker, choose length as indicated	Cable length 3 metre	GCB5	**407994**
		Cable length 3,5 metre	GCB6	**407995**
		Cable length 4 metre	GCB7	**407996**
	Breaker 2: 2 cables choose length as indicated			

Time delay module for UVR release type: TDM



	Cat. No.	Ref. No.
110-130V DC	GTDM120D	**407819**
220-240V DC	GTDM240D	**407821**
110-130V AC	GTDM120A	**407818**
220-240V AC	GTDM240A	**407820**
380- 415V AC	GTDM400A	**407824**

GT- Accessories



Designation	Cat. No.	Ref. No.
Power supply 222-265V- AC-24VDC 0.22Amps	GAPU	**408789**
Trip unit, sealable transparent front cover	GTUS	**408046**
Trip unit tester & No Voltage setup unit	GTUTK20	**407999**

Locking and Interlocking



Designation	Cat. No.	Ref. No.
Front Fascia of Breaker		
Padlocking device for Pushbuttons	GPBD	**408040**
Cassette		
Mis insertion device	LREPM	**444246**
Door		
Interlock on LEFT envelope 1	L1LHD	**444240**
Interlock on RIGHT envelope 1	L1RHD	**444241**
Interlock on LEFT envelope 2	L2LHD	**444242**
Interlock on RIGHT envelope 2	L2RHD	**444243**

(1) See for associated breaker and or cassette mounted kits page A.10

Spare Parts for Power Circuit Breakers

		Envelope 1		Envelope 2	
		Cat. No.	**Ref. No.**	**Cat. No.**	**Ref. No.**
Breaker arc chutes					
	Arc chute for 1 pole	L25NCHT	**444407**	L40DCHT	**444411**
Breaker fixed arcing contacts					
	Set for 1pole all tiers [1]	L25DARC	**444404**	L40DARC	**444410**
Breaker: Door flanges					
	Door flange fixed [1]	LDPRF	**444200**	LDPRF	**444200**
	Door flange drawout [1]	GDPRW	**408026**	GDPRW	**408026**
IP54 cover					
	Front facia cover IP54	G54DR	**408038**	G54DR	**408038**
Cassette racking handle					
	Racking handle [1]	LRHN	**444412**	LRHN	**444412**
Breaker front fascia part[1]					
	Front fascia 3 or 4 pole [2]	LFAL1	**444413**	LFAL2	**444414**
Cassette cluster contacts					
	Sets per pole [1]				
	Current rating 400-1250A	L13NCLS	**444405**		
	Current rating 1600A	L16NCLS	**444406**		
	Current rating 2000-2500A	L25NCLS	**444408**		
	Current rating 2000-4000A			L40DCLS	**444409**
	Set of universal cluster pliers	GUNI	**408047**	GUNI	**408047**
Disconnect terminals					
	For fixed or drawour breaker (B & C block 32 pole) (1)	LSDT	**444415**	LSDT	**444415**
Lifting beam					
	Lifting beam for use with standard lifting equipment	GLB1	**408045**	GLB1	**408045**

(1) Is a spare, these parts are always supplied with the breaker
(2) The original breaker serial number must be indicated on ordering

Retrofit of existing M-Pact breakers with EntelliGuard L

- Kits applicable for the replacement of complete envelope/frame 1 breakers in a fxed or draw out pattern with cassette.
- Envelope/frame 2 breakers do not require a retrofit kit.
- Allows the use of the existing connection material and fixation holes.
- For the replacement envelope 1 or 2 breaker a new front panel cut out is needed.

Existing Breaker	M-Pact in fixed pattern - Frame 1					
	↓					
Replacement Breaker	EntelliGuard L in fixed pattern - Envelope 1					
	↓					
Replacement kit		S type rating 400-1600A		N type rating 400-1600A		S & N types 2000 & 2500A	
		Cat. No.	Ref. No.	Cat. No.	Ref. No.	Cat. No.	Ref. No.
3pole		SMS31F16L16S	**444465**	SMN31F16L16N	**444470**	SMN31F25L25N	**444475**
4pole		SMS41F16L16S	**444466**	SMN41F16L16N	**444471**	SMN41F25L25N	**444476**

Existing Breaker	M-Pact in draw-out pattern - Frame 1							
	↓							
Replacement Breaker	EntelliGuard L in draw-out pattern (1) - Envelope 1							
	↓							
Replacement Kit	S type rating 400-1250A		S type rating 1600A		N type rating 400-1600A z		S & N types 2000 & 2500A	
	Cat. No.	Ref. No.	Cat. No.	Ref. No.	Cat. No.	Ref. No.	Cat. No.	Ref. No.
3pole	SMS31W12L13S	**444480**	SMS31F16L16S	**444485**	SMN31W16L16N	**444490**	SMN31W25L25N	**444495**
4pole	SMS41W12L13S	**444481**	SMS41F16L16S	**444486**	SMN41W16L16N	**444491**	SMN41W24L25N	**444496**

Global Catalogue number structure - Breaker

- Codes built in the indicated manner can be used as an alternative ordering method
- The breaker and its operation mode (manual or electrical)



(1) For an overview of the valid combinations indicating the available options see page A.19

Global Catalogue number structure - Breaker

- Codes built in the indicated manner can be used as an alternative ordering method
- Breaker mounted accessories

9th digit

Shunt Release	
Voltage Rating	Code
24V DC	A
40-48VDC 48V AC	B
110-130V AC-DC	E
220-240V AC-DC	G
380-415V AC	K
None	X

Add Shunt Release by indicating voltage rating code. if not needed use an X as indicated.

11th digit

Reserved for Future use	Code
	X

13th digit

Bell Alarm Contact,Operations Counter & Ready to Close Contact		
Bell Alarm 1 NO	A	D
Mechanical Operations Counter	B	K
Bell Alarm 1NO & Mechanical Operations counter	C	G
Ready to Close contact 1 NO	1	
None	X	X
	No other contacts installed	Ready to Close contact 1 NO Power Rated on Secondary terminals

15th digit

Factory Installed prevision to mount a Cable interlock beween breakers.	
Mechanical Interlock - Type A	R
Mechanical Interlock - Type B	K
Mechanical Interlock - Type C	C
Mechanical Interlock - Type D	D
No prevision for Breaker interlock	X

A X X 2 X X X XX

10th digit

Undervoltage Release	
Voltage Rating	Code
24V DC	1
40-48VDC 48V AC	3
110-130V AC-DC	5
220-240V AC-DC	8
380-415V AC	W
None	X

Add UVR release by using the indicated code. The use of an X indictates no Release installed.

12th digit

Auxiliary Switches	
Type	Code
3NO+3NC (Power Rated)[2]	2
4NO+4NC (Power Rated)	4

14th digit

Factory Installed prevision to mount a Key lock on the breakers	
For Profalux Key lock	P
For Ronis Key lock	R
For 19mm Castell type Key lock	B
Pushbutton Padlock Device	L
Ronis Key Interlock & Push Button Padlock Device	3
Profalux Key Interlock & Push Button Pad. Device	4
Small19m Castell Key Interlock & Push Button Pad. Device	5
No prevision for Key lock	X

16, 17th & 18th digit

Defines Installed GT type Electronic Trip Unit			
Basic type	Code	Functionality	Code
GT-L with Ammeter	L	LT, LTD. ST, STD	01
		LT, LTD. ST, STD, GF & GFD	02
		LT, LTD. ST, STD & I	06
		LT, LTD. ST, STD, I, GF & GFD	07
No prevision for Trip Unit			
	X		XX

(1) Each standard breaker or Isolator is normally supplied with 3 NO+3NC auxiliary contacts (option 2)

Global Catalogue number structure - Cassettes

- Codes built in the indicated manner can be used as an alternative ordering method
- Cassettes for uses with drawout breakers


1st digit
3rd & 4th digit
6th digit
7th digit
9th digit
A product belonging to the EntelliGuard™ L breaker line
Nominal current rating of the product
1250A 13
1600A 16
2000A 20
2500A 25
3200A 32
4000A 40
Number of Poles of the Cassette
3 pole 2
4 pole 5
Connection Mode
Rear Universal, T stubs rotatable -Horizontal or Vertical busbars. U
Front Flat access F
Rear Horizontal busbars H
Rear Vertical busbars V
Factory Installed prevision to mount a Key lock on the cassette
For 1 Ronis Key lock R
For 1 Profalux Key lock P
No Lock Prevision mounted X
L G 13 H 2 U (1) X X M
Suitable for:
Standard Circuit Breaker or standard Non Automatic type G
Interruption / short-circuit withstand rating of the Breaker used with the Cassette.
Icu, Ics or Icw
Envelope
Code
< = 50kA 1 S
65kA 1 N
< = 65kA 2 D
Position Indication switches in Cassette
Set of 1 NO and 1NC contacts per Position 2
Set of 2 NO and 2NC contacts per Position 4
No Switches Mounted X
Delivered mounted with breaker or separately (2)
Mounted with breaker XXM
Delivered as separate component XXR
2nd digit
5th digit
8th digit
10th, 11th & 12th digit (2)

(1) For an overview of the valid combinations indicating the available options see page A.20
(2) Digit 10 and 11 are reserved for future use, a filler "XX" is used

Power Circuit Breakers, Valid Catalogue number combinations

Available standard Breakers, Cassette types and Trip Units

3 & 4 pole Breakers and Isolators in Fixed Pattern		
Cat. No	**Ref. No.**	**Page**
LG04N4	**444078**	A.4-6
LG04N6	**444112**	A.4-6
LG04S4	**444066**	A.4-6
LG04S6	**444100**	A.4-6
LG07N4	**444079**	A.4-6
LG07N6	**444113**	A.4-6
LG07S4	**444067**	A.4-6
LG07S6	**444101**	A.4-6
LG08N4	**444080**	A.4-6
LG08N6	**444114**	A.4-6
LG08S4	**444068**	A.4-6
LG08S6	**444102**	A.4-6
LG10N4	**444081**	A.4-6
LG10N6	**444115**	A.4-6
LG10S4	**444069**	A.4-6
LG10S6	**444103**	A.4-6
LG13N4	**444082**	A.4-6
LG13N6	**444116**	A.4-6
LG13S4	**444070**	A.4-6
LG13S6	**444104**	A.4-6
LG16N4	**444083**	A.4-6
LG16N6	**444117**	A.4-6
LG16S4	**444071**	A.4-6
LG16S6	**444105**	A.4-6
LG20C4	**444074**	A.4-6
LG20C6	**444108**	A.4-6
LG20D4	**444086**	A.4-6
LG20D6	**444120**	A.4-6
LG20N4	**444084**	A.4-6
LG20N6	**444118**	A.4-6
LG20S4	**444072**	A.4-6
LG20S6	**444106**	A.4-6
LG25C4	**444075**	A.4-6
LG25C6	**444109**	A.4-6
LG25D4	**444087**	A.4-6
LG25D6	**444121**	A.4-6
LG25N4	**444085**	A.4-6
LG25N6	**444119**	A.4-6
LG25S4	**444073**	A.4-6
LG25S6	**444107**	A.4-6
LG32C4	**444076**	A.4-6
LG32C6	**444110**	A.4-6
LG32D4	**444088**	A.4-6
LG32D6	**444122**	A.4-6
LG40C4	**444077**	A.4-6
LG40C6	**444111**	A.4-6
LG40D4	**444089**	A.4-6
LG40D6	**444123**	A.4-6
LJ04R4	**444161**	A.4-6
LJ04R6	**444173**	A.4-6
LJ07R4	**444162**	A.4-6
LJ07R6	**444174**	A.4-6
LJ08R4	**444163**	A.4-6
LJ08R6	**444175**	A.4-6
LJ10R4	**444164**	A.4-6
LJ10R6	**444176**	A.4-6
LJ13R4	**444165**	A.4-6
LJ13R6	**444177**	A.4-6
LJ16R4	**444166**	A.4-6
LJ16R6	**444178**	A.4-6
LJ20C4	**444169**	A.4-6
LJ20C6	**444181**	A.4-6
LJ20R4	**444167**	A.4-6
LJ20R6	**444179**	A.4-6
LJ25C4	**444170**	A.4-6
LJ25C6	**444182**	A.4-6
LJ25R4	**444168**	A.4-6
LJ25R6	**444180**	A.4-6
LJ32C4	**444171**	A.4-6
LJ32C6	**444183**	A.4-6
LJ40C4	**444172**	A.4-6
LJ40C6	**444184**	A.4-6

3 & 4 pole Breakers and Isolators drawout portion only		
Cat. No	**Ref. No.**	**Page**
LG04N1	**444012**	A.4-6
LG04N3	**444045**	A.4-6
LG04S1	**444000**	A.4-6
LG04S3	**444033**	A.4-6
LG04S3	**444033**	A.4-6
LG07N1	**444013**	A.4-6
LG07N3	**444046**	A.4-6
LG07S1	**444001**	A.4-6
LG07S3	**444034**	A.4-6
LG07S3	**444034**	A.4-6
LG08N1	**444014**	A.4-6
LG08N3	**444047**	A.4-6
LG08S1	**444002**	A.4-6
LG08S3	**444035**	A.4-6
LG08S3	**444035**	A.4-6
LG10N1	**444015**	A.4-6
LG10N3	**444048**	A.4-6
LG10S1	**444003**	A.4-6
LG10S3	**444036**	A.4-6
LG10S3	**444036**	A.4-6
LG13N1	**444016**	A.4-6
LG13N3	**444049**	A.4-6
LG13S1	**444004**	A.4-6
LG13S3	**444037**	A.4-6
LG13S3	**444037**	A.4-6
LG16N1	**444017**	A.4-6
LG16N3	**444050**	A.4-6
LG16S1	**444005**	A.4-6
LG16S3	**444038**	A.4-6
LG16S3	**444038**	A.4-6
LG20C1	**444008**	A.4-6
LG20C3	**444041**	A.4-6
LG20D1	**444020**	A.4-6
LG20D3	**444053**	A.4-6
LG20N1	**444018**	A.4-6
LG20N3	**444051**	A.4-6
LG20S1	**444006**	A.4-6
LG20S3	**444039**	A.4-6
LG20S3	**444039**	A.4-6
LG25C1	**444009**	A.4-6
LG25C3	**444042**	A.4-6
LG25D1	**444021**	A.4-6
LG25D3	**444054**	A.4-6
LG25N1	**444019**	A.4-6
LG25N3	**444052**	A.4-6
LG25S1	**444007**	A.4-6
LG25S3	**444040**	A.4-6
LG25S3	**4 44040**	A.4-6
LG32C1	**444010**	A.4-6
LG32C3	**444043**	A.4-6
LG32D1	**444022**	A.4-6
LG32D3	**444055**	A.4-6
LG40C1	**444011**	A.4-6
LG40C3	**444044**	A.4-6
LG40D1	**444023**	A.4-6
LG40D3	**444056**	A.4-6
LJ04R1	**444135**	A.4-6
LJ07R1	**444136**	A.4-6
LJ08R1	**444137**	A.4-6
LJ10R1	**444138**	A.4-6
LJ13R1	**444139**	A.4-6
LJ16R1	**444140**	A.4-6
LJ20C1	**444143**	A.4-6
LJ20C3	**444155**	A.4-6
LJ20R1	**444141**	A.4-6
LJ25C1	**444144**	A.4-6
LJ25C3	**444156**	A.4-6
LJ25R1	**444142**	A.4-6
LJ32C1	**444145**	A.4-6
LJ32C3	**444157**	A.4-6
LJ40C1	**444146**	A.4-6
LJ40C3	**444158**	A.4-6

3 & 4 pole Cassettes, supplied with breakers		
Cat. No	**Ref. No.**	**Page**
LG13S2FM	**444270**	A.5-7
LG13S2HM	**444272**	A.5-7
LG13S2UM	**444271**	A.5-7
LG13S5FM	**444273**	A.5-7
LG13S5HM	**444275**	A.5-7
LG13S5UM	**444274**	A.5-7
LG16S2FM	**444276**	A.5-7
LG16S2HM	**444278**	A.5-7
LG16S2UM	**444277**	A.5-7
LG16S5FM	**444279**	A.5-7
LG16S5HM	**444281**	A.5-7
LG16N5UM	**444280**	A.5-7
LG20N2HM	**444284**	A.5-7
LG20N5HM	**444287**	A.5-7
LG25N2FM	**444282**	A.5-7
LG25N2UM	**444283**	A.5-7
LG25N5FM	**444285**	A.5-7
LG25N5UM	**444286**	A.5-7
LG32D2HM	**444289**	A.5-7
LG32D2UM	**444288**	A.5-7
LG32D5HM	**444291**	A.5-7
LG32D5UM	**444290**	A.5-7
LG40D2VM	**444292**	A.5-7
LG40D5VM	**444293**	A.5-7

3 & 4 pole Cassettes, supplied separatley		
Cat. No	**Ref. No.**	**Page**
LG13S2FR	**444300**	A.12
LG13S2HR	**444302**	A.12
LG13S2UR	**444301**	A.12
LG13S5FR	**444303**	A.12
LG13S5HR	**444305**	A.12
LG13S5UR	**444304**	A.12
LG16S2FR	**444306**	A.12
LG16S2HR	**444308**	A.12
LG16S2UR	**444307**	A.12
LG16S5FR	**444309**	A.12
LG16S5HR	**444311**	A.12
LG16S5UR	**444310**	A.12
LG20N2HR	**444314**	A.12
LG20N5HR	**444317**	A.12
LG25N2FR	**444312**	A.12
LG25N5FR	**444315**	A.12
LG25N5UR	**444316**	A.12
LG25N5UR	**444316**	A.12
LG32D2HR	**444319**	A.12
LG32D2UR	**444318**	A.12
LG32D5HR	**444321**	A.12
LG32D5UR	**444320**	A.12
LG40D2VR	**444322**	A.12
LG40D5VR	**444323**	A.12

Trip Units and their accessories		
Cat. No	**Ref. No.**	**Page**
GAPU	**408789**	A.14
GTUS	**408046**	A.14
GTUTK20	**407999**	A.14
LTG00K1XXSF	**444260**	A.14
LTG00K2XXSF	**444261**	A.14
LTG00K3XXS	**444263**	A.14
LTG00K9XXSF	**444262**	A.14
L104NRC	**444420**	A.14
L106NRC	**444421**	A.14
L108NRC	**444422**	A.14
L110NRC	**444423**	A.14
L113NRC	**444424**	A.14
L116NRC	**444425**	A.14
L120NRC	**444426**	A.14
L125NRC	**444428**	A.14
L220NRC	**444427**	A.14
L225NRC	**444429**	A.14
L232NRC	**444430**	A.14
L240NRC	**444432**	A.14

Power Circuit Breakers, Valid Catalogue number combinations

Available Accessories

Factory Mounted accessories		
Cat. No	**Ref. No.**	**Page**
GCCN024D	**407861**	A.9
GCCN120	**407867**	A.9
GCCN120	**407867**	A.9
GCCN240	**407869**	A.9
GCCN240	**407869**	A.9
GM01024D	**407700**	A.9
GM01110D	**407706**	A.9
GM01120A	**407712**	A.9
GM01220D	**407720**	A.9
GM01240A	**407714**	A.9
GMCN	**408035**	A.9
GRTC1	**407897**	A.9
GSTR024D	**407770**	A.9
GSTR048	**407772**	A.9
GSTR120	**407776**	A.9
GSTR240	**407778**	A.9
GSTR400A	**407782**	A.9
GUVT024D	**407795**	A.9
GUVT048	**407797**	A.9
GUVT120	**407801**	A.9
GUVT240	**407803**	A.9
GUVT400A	**407807**	A.9
LAS3	**444205**	A.9
LAS4	**444206**	A.9
LBAT1	**444207**	A.9
LBCA9	**444214**	A.9
LBPRO	**444211**	A.9
LBRON	**444212**	A.9
LCPRO	**444215**	A.9
LCPS1	**444230**	A.9
LCPS2	**444232**	A.9
LCRON	**444216**	A.9
LI2FAD	**444221**	A.10
LI2FAD	**444221**	A.10
LI2WAD	**444222**	A.10
LI2WAD	**444222**	A.10
LI3FB	**444223**	A.10
LI3FC	**444225**	A.10
LI3FDT	**444227**	A.10
LI3WB	**444224**	A.10
LI3WC	**444225**	A.10
LI3WDT	**444228**	A.10
LM01024D	**444190**	A.9
LM01110D	**444191**	A.9
LM01120A	**444193**	A.9
LM01220D	**444192**	A.9
LM01240A	**444194**	A.9

Field Mountable accessories & spares		
Cat. No	**Ref. No.**	**Page**
GAPU	**408789**	A.13
GCB1	**407990**	A.13
GCB2	**407991**	A.13
GCB3	**407992**	A.13
GCB4	**407993**	A.13
GCB5	**407994**	A.13
GCB6	**407995**	A.13
GCB7	**407996**	A.13
GCCN024DR	**407860**	A.11
GCCN120R	**407866**	A.11
GCCN120R	**407866**	A.11
GCCN240R	**407868**	A.11
GCCN240R	**407868**	A.11
GM01024DR	**407701**	A.11
GM01110DR	**407707**	A.11
GM01120AR	**407713**	A.11
GM01220DR	**407721**	A.11
GM01240AR	**407715**	A.11
GMCNR	**408033**	A.11
GPBD	**408040**	A.13
GPRO	**407986**	A.11
GREPM	**408041**	A.13
GRON	**407985**	A.11
GSTR024DR	**407771**	A.11
GSTR048R	**407773**	A.11
GSTR120R	**407777**	A.11
GSTR240R	**407779**	A.11
GSTR400AR	**407783**	A.11
GTDM120A	**407818**	A.13
GTDM120D	**407819**	A.13
GTDM240A	**407820**	A.13
GTDM240D	**407821**	A.13
GTDM400A	**407824**	A.13
GTUS	**408046**	A.13
GTUTK20	**407999**	A.13
GUVT024DR	**407796**	A.11
GUVT048R	**407798**	A.11
GUVT120R	**407802**	A.11
GUVT240R	**407804**	A.11
GUVT400AR	**407808**	A.11
L1CTC1	**444450**	A.12
L1CTC3	**444451**	A.12
L1LHD	**444240**	A.13
L1RHD	**444242**	A.13
L2CTC1	**444452**	A.12
L2CTC3	**444453**	A.12
L2LHD	**444241**	A.13
L2RHD	**444243**	A.13
LAS3R	**444208**	A.11
LAS4R	**444209**	A.11
LBAT1R	**444210**	A.11
LCPS1R	**444231**	A.11
LCPS2R	**444233**	A.11
LM01024DR	**444195**	A.11
LM01110DR	**444196**	A.11
LM01120AR	**444198**	A.11
LM01220DR	**444197**	A.11
LM01240AR	**444199**	A.11
LPBD	**444213**	A.13

Spare parts		
Cat. No	**Ref. No.**	**Page**
G54DR	**408038**	A.14
GDPRW	**408026**	A.14
GLB1	**408045**	A.14
GUNI	**408047**	A.14
L13NCLS	**444405**	A.14
L16NCLS	**444406**	A.14
L25DARC	**444404**	A.14
L25NCHT	**444407**	A.14
L25NCLS	**444408**	A.14
L40DARC	**444410**	A.14
L40DCHT	**444411**	A.14
L40DCLS	**444409**	A.14
LDPRF	**444200**	A.14
LDPRF	**444200**	A.14
LFAL1	**444413**	A.14
LFAL2	**444414**	A.14
LRHN	**444412**	A.14
LSDT	**444415**	A.14

Electronic Trip Units

B.2 Trip Unit layout & Main menu

B.3 Overcurrent protection against Overload, LT-C, LTD

B.4 Trip Unit options and available Long Time current settings

B.5 Overcurrent protection against Short-circuit: ST, STDB and I^2t

B.6 Overcurrent protection against Short-circuit: I, HIOSC and MCR

B.7 Ground fault protection: GF, GFD', I2T and I4T

B.8 Electronic Trip Unit features and accessories

B.9 Time Current curve; LT Overcurrent protection

B.10 Time Current curve; ST Overcurrent protection

B.12 Time Current curve; I Overcurrent protection

B.12 Time Current curve; GF Ground fault protection

B.14 Time Current curves; Terminology

B.15 Time Current curves; Example of Full Time Current curve

Electronic Trip Units layout & Main menu

State of the Art Electronic Trip Unit
EntelliGuard™ L Power Circuit Breakers is equipped with a digital electronic trip unit type GT-L, that has a LCD screen providing an ammeter and a touchpad that allows a simple and accurate menu driven adjustment of the breaker parameters.
All functionality is menu driven accessed by using 4 setting and one enter key thus allowing a fast and accurate setting of the device. These have the following functionality.

UP: Scroll up, Increment Value
DOWN: Scroll down, Decrement value
NEXT function, next page
PREVIOUS function, previous page
SAVE setting into memory

In situations where the installation is not yet connected to the power supply and the device needs to be adjusted and have the installed options set the use of the separately available TESTER with Power Pack is advised. (Cat No. GTUTK20)
In Power On situations the Trip Unit display is only functional when the breaker is carrying at least 20% of it's nominal current value. (Single phase)



SET UP MENU
To enter this option begin the process by pressing the UP or DOWN key until SETUP is selected on the screen... Pressing the NEXT or PREVIOUS key allows one to enter the setup mode.
After selecting this mode all functions can be chosen by depressing the NEXT or PREVIOUS key.
Within the setup menu all breaker protection values, trip unit parameters, relaying functions in and outputs, communication and trip unit access codes are set.
Each EntelliGuard™ L Electronic trip units provides long-time over-current protection (**LT**), long-time delay (**LTD/t_R**) and some form of Short Circuit over-current protection (**ST and/or I**). Optionally Groundfault protection (GFsum) with a delay funtion (GFDB/T_G) can be added.

METER
To enter this option begin the process by pressing the UP or DOWN key until to METER is selected on the screen.. Pressing the NEXT or PREVIOUS key allows one to view the current in all three phases and the neutral. The ammeter is only available when the trip unit is powered by the distribution or via the external Testkit.

STATUS
To enter this option begin the process by pressing the UP or DOWN key until METER is selected on the screen. The status option indicates the present status and settings of the trip unit and circuit breaker.

EVENTS
To enter this option begin the process by pressing the UP or DOWN key until EVENTS is selected on the screen. Pressing the NEXT or PREVIOUS key allows one to access events. Here a total of 10 events with data as, event type and event magnitude are stored. The connection of a 24V DC auxiliary supply to the Trip Unit will expand this option to include a time stamp of each event.
Tripping events as LT, ST, I GF) are visualized with the associated levels. It is possible to clear this so called "trip register" locally.

Overload Protection LT-C and LTD

Overload (LT-C) Protection
The EntelliGuard™ GT-L Electronic Trip has an extremely accurate and easy to set overload or Long Time (LT-C) Protection . It is designed to pick up overloads that exceed 112% of the set value within two hours with a tolerance of 10% (1).

The device has 15 setpoints distributed over a setting range of 0.4 to 1 times the chosen breaker rating (In)

The LT-C type is designed to be used in association with down- and upstream circuit breakers and has a so called I^2t shape producing a curve form similar to standard industrial thermal magnetic protection devices.

The Time-Current protection curve depicted here is drawn in cold state A cooling function in the device corrects for the heating of the connected lines and equipment.

In order to allow an accurate adjustment to the thermal properties of the protected equipment and to finely match the curve with those of Upstream & Downstream devices 22 time bands are available.

The table indicates the minimum delay time and maximum total interruption times for 3 frequently used reference points on the curve of each band. The graph portrays the LT behaviour for the time-current bands C-4,C- 8, C-13 & C-22.





Overload Tripping times at indicated overload levels per selected LTD band, in Seconds

x Ir		Cmin	C-2	C-3	C-4	C-5	C-6	C-7	C-8	C-9	C-10	C-11	C-12	C-13	C-14	C-15	C-16	C-17	C-18	C-19	C-20	C-21	Cmax
1.5	*Max.*	7,8	23,4	46,7	62,3	93,4	125	156	187	218	249	280	311	374	436	498	560	623	685	747	810	872	934
	Min.	4,0	12,0	24,0	32,0	48,0	64,1	80,1	96,1	112	128	144	160	192	224	256	288	320	352	384	416	448	480
3	*Max.*	1,3	3,86	7,73	10,3	15,5	20,6	25,8	30,9	36,1	41,2	46,4	51,5	61,8	72,1	82,4	92,7	103	113	124	134	144	155
	Min.	0,80	2,41	4,82	6,43	9,64	12,9	16,1	19,3	22,5	25,7	28,9	32,1	38,6	45,0	51,4	57,8	64,3	70,7	77,1	83,6	90,0	96,4
7.2	*Max.*	0,21	0,62	1,24	1,66	2,49	3,32	4,15	4,98	5,81	6,64	7,47	8,30	9,96	11,6	13,3	14,9	16,6	18,3	19,9	21,6	23,2	24,9
	Min.	0,13	0,40	0,81	1,07	1,61	2,15	2,69	3,22	3,76	4,30	4,83	5,37	6,45	7,52	8,60	9,67	10,7	11,8	12,9	14,0	15,0	16,1
Motor Protection Class to IEC 947-4							**10b**				**10**			**20**			**30**			**40**			

(1) Meeting the requirements of IEC 90647-2 and IEC 90647-4

Trip Unit Functionality & available Long Time settings

Trip Unit functionality		GT-L
Setting interface	LCD Screen allowing access to 4 distinct menu's	X
	Touch pad adjustments	X
	Multilingual	X
	Adjustable manual or automatic RESET option	X
Long time or overload current protection	Ir=0.4 to 1In 15 secondary current settings	X
	22 Thermal Protection (C type) time bands available ranging from class 0.5 to 40 (bands at 7.2 x Ir)	X
	Neutral Protection 0-50%-63%-100%	X
	Cooling function and Thermal memory	X
Short time short-circuit current protection	Setting range from **1.5 to 12** x Ir (LT setting)	X
	Steps of 0.5 (A total of 22 settings)	X
	17 time delay settings **(STDB)** ranging from 30 to 940 milliseconds delay setting result in a 90 to 1000 milliseconds clearing time	X
	Clearance times to IEC 40979-1 and IEC 60364	X
	3 I^2t Protection time bands available	X
Instantaneous Short-circuit Current Protection	Ii setting range from **2 to 15** x In	X
	Steps of 0.5 (A total of 28 settings)	X
	Possibility to switch **OFF**	X
	Selective execution	X
	Fixed instantaneous or HSIOC protection	X
Ground Fault Protection	Setting range from **0.2 to 1** x In (Breaker rating)	O
	Steps of 0.01 (A total of 92 settings)	O
	Possibility to switch **OFF**	O
	14 time delay settings **(GFDB)** ranging from 50 to 840 milliseconds delay setting resulting in a 110 to 900 milliseconds clearing time	O
	Clearance times to IEC 40979-1 and IEC 60364	O
	3 I^2t protection time bands available	O
	Residual principle	O
Data Acquisition & Diagnostics	Trip Target (trip reason indication)	X
	Trip Info (Magnitude / Phase)	X
	Trip Counter	X
	Event Logger (trip events)	X
	Good & Bad Health Indicator	X
Other	24V DC Auxiliary power supply	O
	Test kit with power support function	O

Key:
X = Present
O = Optional

Trip Unit LT settings

Breaker In (A)	400	630	800	1000	1250
GT-L Setting x In	Available Setpoints (A)				
0,4	160	252	320	400	500
0,45	180	284	360	450	563
0,5	200	315	400	500	625
0,55	220	347	440	550	688
0,6	240	378	480	600	750
0,65	260	410	520	650	813
0,7	280	441	560	700	875
0,75	300	473	600	750	938
0,8	320	504	640	800	1000
0,75	300	473	600	750	938
0,8	320	504	640	800	1000
0,85	340	536	680	850	1063
0,9	360	567	720	900	1125
0,95	380	599	760	950	1188
1	400	630	800	1000	1250

Breaker In (A)	1600	2000	2500	3200	4000
GT-L Setting x In	Available Setpoints (A)				
0,4	640	800	1000	1280	1600
0,45	720	900	1125	1440	1800
0,5	800	1000	1250	1600	2000
0,55	880	1100	1375	1760	2200
0,6	960	1200	1500	1920	2400
0,65	1040	1300	1625	2080	2600
0,7	1120	1400	1750	2240	2800
0,75	1200	1500	1875	2400	3000
0,8	1280	1600	2000	2560	3200
0,75	1200	1500	1875	2400	3000
0,8	1280	1600	2000	2560	3200
0,85	1360	1700	2125	2720	3400
0,9	1440	1800	2250	2880	3600
0,95	1520	1900	2375	3040	3800
1	1600	2000	2500	3200	4000

Short-circuit Protection ST and STDB

Overcurrent Protection against short-circuit: ST, STDB
The EntelliGuard™ GT-L Electronic Trip and breaker combination can be equipped with a number of different short-circuit protection devices each with their own distinctive properties and field of application.

The Timed Short-circuit Protection Device is designed to offer selectivity over a defined current range and offers a unique combination of multiple time bands and current settings.

To allow selectivity with a wide range of different downstream devices whilst not unnecessarily sacrificing clearing time, 17 different time bands are available. The device has an adjustment range of 1.5 to 12 (+-10%) times the chosen Long Time current value (Ir) in steps of 0,5 (pick up setting).

The graph indicates 6 of the available 17 time bands across the full adjustment range. The table contains the minimum delay time and the maximum total interruption times for all time band settings.

Timed Short-circuit (ST) Protection I^2t bands (slope)
The ST device can also be set to a I^2t slope value. The available multiple I^2t slopes are normally used to achieve selectivity with downstream fuses or to improve selectivity with downstream circuit breakers.

The device has an adjustment range of 1.5 to 12 (+-10%) times the chosen Long Time current value (Ir) in steps of 0.5 (pick up setting) and 17 time bands.

There are three available I^2t slopes (K set at 3,8 or 18) .





Short time tripping times at indicated levels per selected STDB band - I^2t OFF, in milliseconds

	x Ir	Min	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	Max
1.5 x ±10%	*Tripping*	90	100	110	120	170	190	240	270	300	340	400	450	600	700	800	900	1000
	Non Tripping	30	40	50	60	110	130	180	210	240	280	340	390	540	640	740	840	940
12 x ±10%	*Tripping*	90	100	110	120	170	190	240	270	300	340	400	450	600	700	800	900	1000
	Non Tripping	30	40	50	60	110	130	180	210	240	280	340	390	540	640	740	840	940

Short-circuit Protections, I, HIOSC & MCR

Instantaneous Short-circuit (I) Protection
A user settable device that allows a high speed fault interruption at a pre-determined current level. This device can be used with the short time delayed (ST) short-circuit protection device or as replacement thereof. The device has a current adjustment of 2 to 15 (±10%) times the chosen Primary Current Value (Ie) in steps of 0.5.
The device can also be switched OFF.
On breakers with a rating of more than 4000A the maximum setting of 15 x is in some cases limited to a lower value due to the breaker current rating and its Short-circuit withstand value (see page B.11).
The Instantaneous tripping system used in the EntelliGuard Electronic Trip Unit has a unique programming feature that waits for the downstream device to trip before reacting to an overcurrent fault. This providing the user with a unique combination of **Speed** and **Selectivity**.

The graph indicates the maximum interruption time and non tripping time across the full current setting band and the trasnition to the HIOS protection device.





HSIOC Protection device
To prevent very hi level short-circuit currents causing damage to their electrical installation and their components EntelliGuard Power Circuit Breaker are equipped with a HSIOC protection device.

This hi level short-circuit device is installed in all EntelliGuard L Breakers and is designed to trip the breaker at the specified Icw value of the device). The device, interrupts and thus limits the duration of these high level short-circuits to 40 milliseconds.

Making Current (MCR) Protection device
If a breaker is closed on to a short-circuit current it is mandatory that the device interrupts before the electrical installation and it's components incur any damage .

An MCR device is present in all EntelliGuard Power Circuit Breakers) specifically designed to trip the breaker when closing onto a fault.

Ground Fault Protections GF & GFD

Ground Fault Protection (GFsum)

To protect an installation or a part thereof against indirect contact, Protection Devices can be used to automatically disconnect the power supply when a fault to earth is detected. The HD384 installation standard requires that the mentioned device senses the fault and then interrupts the supply within a specified time frame.

A short-circuit device as an EntelliGuard Power Circuit Breaker can be used to meet this requirement. However these short-circuit protection devices are normally set at values that are too high to detect normally occurring faults to Earth.

The optionally available Ground Fault protection feature is specifically designed to detect lower currents than a standard short-circuit Device and operate by residually summing the current in the Phases and Neutral. When a fault to Earth creates an unbalance in the system the resulting Fault Current is detected by the device that produces an alarm signal or trips the associated circuit breaker thus disconnecting the circuit.

The EntelliGuard Ground fault device has an adjustment range of 0.2 to 1 (±15%) times the chosen breaker rating (In) and can be set in steps of 0,01 (pick up setting). To allow selectivity with other downstream protection devices there are 14 different time band settings available.

The graph indicates a number of the available 14 time bands across the full adjustment range.

The table contains the minimum delay time and the maximum total interruption times for all time band settings.

The Ground fault device must monitor the current in all phases and the Neutral. When a 3 pole device is used in a 4 wire (3phase + Neutral) system a 4th sensor must be placed in the Neutral. On use of a 4 pole EntelliGuard breaker the sensor is already present in the Neutral pole.





Ground Fault Protection I^2t or I^4t bands (slope)

The GF device can also be set to a slope value. The available multiple I^2t and I^4t slopes are normally used to achieve selectivity with downstream fuses or to improve selectivity with downstream circuit breakers.

The user has the possibility to choose a current adjustment of 0.2 to 1 (times the chosen the chosen breaker rating (In) in steps of 0.01 and one of 14 time bands.

There are three available slopes: Low, Medium and High.

Ground fault tripping times at indicated levels per selected GFDB band -I^2t slope OFF, in milliseconds

	x Ir	1	2	3	4	5	6	7	8	9	10	11	12	13	14
0.2 x	*Tripping*	110	120	140	170	190	240	270	340	400	450	600	700	800	900
±10%	*Non Tripping*	50	60	80	110	130	180	210	280	340	390	540	640	740	840
0.6 x	*Tripping*	110	120	140	170	190	240	270	340	400	450	600	700	800	900
±10%	*Non Tripping*	50	60	80	110	130	180	210	280	340	390	540	640	740	840

Measurement Functions and Power Supplies

Ammeter
An Ammeter is supplied with each EntelliGuard™ Electronic Trip Unit. The current in each of the three phases and the Neutral can be viewed.
The device has an accuracy of 2% when viewed at the nominal current of the breaker and an accuracy of 5% when viewed when the breaker is running at 50 - 85% of its full load.

Parameter	Measured	Units	Resolution	Accuracy at 100% of breaker rating
Current	L1, L2, L3, N	A	0000	2%



Trip Reason Indicators (event logging)
Trip Operations counter.
The Electronic Trip Unit keeps track of data indicating why the associated breaker has tripped and on how many occurrences have taken place. Accessible under the 'EVENTS' menu the Trip Reason Indicator keeps track of a maximum of 10 events that have caused the EntelliGuard breaker to trip. The device stores the voltage, the phase's involved, the current value, the reason of the trip and the trip number (see counter). When an auxiliary voltage is connected the time and date of the event are also stored.

Accessible under the 'STATUS' menu the Trip Operations Counter registers a maximum of 255 overcurrent faults with their reason. (LT, ST, I or GF-EF). The data can be viewed and reset through the STATUS menu Pickup status option.

Neutral Protection
When inserted into a 4 pole breaker the EntelliGuard™ Electronic Trip Unit senses that the breaker in which the device is installed has a Neutral Pole. Via the set Up menu, a Neutral Setting option then becomes available in which the

LT, ST and I protection device can be jointly set to one of the following values:
0%, 50%, 63% or 100%. x the values set for the phase protection device.

Reset Choice Function
When a fault has occurred the Trip Unit trips the associated breaker. It is then deemed normal installation practise to verify the reason of the fault before reconnecting power by resetting and switching the breaker on. The advanced options included in the EntelliGuard™ Trip Unit provide the user with the fault reason, magnitude and location, thus allowing the user to easily establish the

required corrective actions. To follow this procedure Trip Unit reset function should be set to MANUAL. However, in some cases it is required that the breaker resets itself automatically. If this functionality is required, the reset function should be set to AUTOMATIC.
A selector switch on the Trip Unit front face allows the user this choice.

Auxiliary Power Supply
The 24V DC auxiliary supply allows of the trip unit setup function when the standard supply is disconnected. At circuit loads >20% the standard power supply allows full uses of the setup option.

The separately available Test Box Kit can also be used as a temporary power supply.
This device has a battery pack and optionally can provide power by using a 24 V DC power supply.



Test Kit
To verify that the Electronic Trip Unit is interfacing correctly with the Breaker and to establish if the circuitry in the Trip Unit is functioning correctly a test kit is available.

The device has a 24V auxiliary supply to allow it's use in a secondary function as power supply of the Trip unit when no network power supply is available. The device can be plugged in to a jack on the trip Unit Front face.

Time Current Curves (cold state)

LT Protection Device









Time Current Curves (cold state)

ST Protection Device









Time Current Curves (cold state)

ST Protection Device









Time Current Curves (cold state)

I & GF Protection Device







Time Current Curves (cold state)

GF Protection Device









Time Current Curves (cold state)

GF Protection Device





Denonimation	Description
In	Current rating of Breaker
Ir	Current setting
LT	Long Time or Overload protection
ST	Short Time or Timed Short circuit protection
I	Instantaneous Short circuit protection *(new IEC refererence I,)*
GF	Groundfault
Ir	LT or overload Current setting
Ist	ST or Timed Short circuit Current setting *(new IEC refererence I_{sp})*
Ii	Instantaneous Short circuit Current setting
Ig	Ground, or Earthfault Current setting
LTDB	LT or overload time delay band *(new IEC refererence t,)*
STDB	ST or short circuit time delay band *(new IEC refererence t_{sp})*
I²t	'Slope' setting on ST or GF device
I⁴t	'Slope' setting on GF device
x LT	Multiple of LT or overload Current setting
x In	Multiple of Breaker Current rating
x CT	Multiple of installed sensor rating *(In IEC EntelliGuard types =In)*
I	Standard Instantaneous
MCR	Making Current Releas
HSIOC	Hi set Instantaneous protection.

Time Current Curves (cold state)

Example of Full Time Current Curve

Time Current Curve
The EntelliGuard™ Electronic trip unit has many sophisticated setting features and an extremely broad setting range. On request we can provide complete Time Current Curves covering all installed protection devices. The curves can be produced for any current setting within the range of the installed protection devices, for one or for a combination of two breakers.
Please contact your local GE Sales Office for more information.



Notes

The Breaker & it's Accessories

C.2 Electrical Operation of Breaker (Motor Operator)
Electrical Operation of Breaker (Closing Coils)
Shunt & Undervoltage Releases
C.3 Time Delay Module for Undervoltage Release
Auxiliary contact packages
Bell Alarm contact
C.4 Spring charged and Ready to Close indication contacts
Operation counter
IP54 cover
Hoisting and Lifting facilities
Pushbutton padlock device
C.5 Locking previsions on Breaker and Cassette
Door interlock
Carriage indication contacts
Spare parts for general use and maintenance purposes
C.6 Mechanical Interlocking of multiple Breakers
C.7 Breaker and Trip Unit schematics

Breaker accessories

Electrical charging mechanism (motor)
In order to charge the stored energy mechanism electrically, a motor mechanism is available. The design allows factory or field mounting and is available for the full range of EntelliGuard breakers. It is easily fitted with just three bolts.



When the circuit breaker is opened, the mechanism automatically recharges the springs and prepares the breaker for an almost instantaneous reclosure should the need arise.

High speed recharging ensures that the springs are fully charged within four seconds. An optional 'ready to close' or 'spring charging indication' contact is available that indicates that the springs have been recharged and that the breaker can be closed.

The device is available in multiple AC and DC voltages and can be used in a operating frequency of up to two operations per minute. It has a life span equivalent to that of the breaker without maintenance. To switch the EntelliGuard breaker ON and OFF remotely a closing coil and shunt release is also necessary.

Connections
The motor mechanism connection points can be found on terminal B of both the fixed pattern and draw-out breaker types. Please refer to page C.7.

Electrical characteristics

Control voltage	Motor operator
	Power consumption
24DC, 110-130DC 220V DC	300W
110-130AC 220 - 240AC	350VA

Closing Coil
To switch the Air Circuit Breaker ON remotely a closing coil is available that when energized releases the spring charged closing mechanism. The device is available as a factory mounted component or as a field mountable device. It is an extremely easy-to-fit, clip-on unit, with simple plug-in connectors. The coils have a life span equivalent to that of the full breaker life span.

Connections
The closing coils connection points can be found on terminal B of both the fixed pattern and draw-out breaker types. Please refer to page C7.

Electrical characteristics

AC	DC	Power consumption
--	24V	350 VA Inrush
--	48V	
110-130V	110-130V	
220-240V	220-240V	
380-415V	--	

Shunt release
A device designed to switch the Air Circuit Breaker OFF remotely. When energized, a shunt release instantaneously activates the circuit breaker mechanism thus ensuring a rapid disconnection of the main contacts (50 msec).
All EntelliGuard shunt release are suitable for a continuous power supply and are designed to be used as a closure prevention device when energized.

The device is available as a factory mounted component or as a field mountable device. It is an extremely easy-to-fit, clip-on unit, with simple plug-in connectors.

The individual devices have a wide voltage range, thus limiting the number of devices needed and have a life span equivalent to that of the full breaker life span.

Undervoltage release
A device designed to open the breaker contacts and to prevent the breaker from closing when in a "No Volt" condition. On a de-energization the undervoltage release activates the circuit breaker mechanism and ensures a rapid disconnection of the main contacts (50 milliseconds). When not re-energized in accordance to the conditions stated in the IEC60947 the device prevents the Air Circuit Breaker from closing.

The EntelliGuard undervoltage releases are designed to react within a pre-defined voltage band, only reacting when the voltage supplying drops below the limits of this band. To prevent nuisance tripping due to short air interruptions or 'Brown Outs' the device has a built in delay of 50 milliseconds.

Breaker accessories

The device is available as a factory mounted component or as a field mountable device. It is an extremely easy-to-fit, clip-on unit, with simple plug-in connectors.

The device have a wide voltage range, thus limiting the number of devices needed and can be used in an operating frequency of up to two operations per minute.

The release can have a life span equivalent to that of the full breakers life span.

Connections

The connection points of both releases (UV and shunt) can be found on terminal B of both the fixed pattern and draw-out breaker types. Please refer to page 51.

Electrical characteristics

AC	DC	Power consumption
--	24V	350 VA / 350 W Inrush 60 VA / 50W Holding
48V*	48V	
110-130V	110-130V	
220-240V	220-240V	
380-415V	--	

* Applicable only to shunt release

Time delay module

The de-energizing operation of the undervoltage release can be delayed. This optional, externally mounted module has an adjustable time delay of zero to three seconds. The device can be implemented to prevent undesired breaker tripping due to momentary voltage interruptions and is connected in series with the undervoltage release.

Optionally, the EntelliGuard trip unit can be supplied with a three phase plus neutral undervoltage protection device that can provide a power interruption alarm and/or initiate a breaker 'trip'.

Electrical characteristics

AC	DC	Power consumption
110-130V	48 V	350 VA Inrush 60 VA Hold
220-240V	110 - 130V	
380-415V	220 - 240V	

Auxiliary contacts

Auxiliary contacts are designed to indicate the position of the Air Circuit Breaker main contacts. Each EntelliGuard device is supplied with a standard package of 3 normaly open (NO) and 3 normally closed (NC) contacts that operate simultaneously with the breakers main contacts. Optionally another package is available that can be used to increase the number of available contacts by replacing the standard auxiliary contact block.

Auxiliary contact packages

Standard: 3 NO + 3 NC power rated
Optional: 4 NO + 4 NC power rated

The devices are available as factory mounted components or as a field mountable device. Auxiliary contact packages are easy-to-fit, and have simple plug-in connectors.

Auxiliary switch characteristics	
Power rated	
Nominial control voltage	**Current rating**
	Non-inductive
AC 50 HZ	Amps
110/120V	10
220/240V	10
380/415V	5
DC	
110/120V	5
220/250V	0.25

Connections

The connection points of the auxiliary contacts can be found on terminal C of both the fixed pattern and draw-out breaker types. When the standard 4 NO + 4 NC is required, only the standard terminal C is used. For other combinations terminal A needs to be ordered separately.

Bell alarm contact

When an EntelliGuard Air Circuit Breaker has tripped due to a fault detected by the trip unit, a bell alarm changeover contact is available to indicate this. The contact can only be used when the breaker is adjusted to "Manual Reset".

Connections

The connection points of the bell alarm contact can be found on terminal B of both the fixed pattern and draw-out breaker types.

Breaker accessories

Electrical characteristics

AC ratings		DC ratings	
Voltage	**Amps**	**Voltage**	**Amps**
250V	AC21-6A	125V	DC21-0.4A
		250V	DC21-0.2A

Minimum operating current 0.1A at 8V DC

Spring charged and ready to close contacts

A breaker with electrical charging mechanism is equipped with a spring charged contact that closes if the spring mechanism is charged.

The second contact is ready to close indication, contact can optionally replaces the spring charge contact. It only changes the indication when the following conditions are met:

- The circuit breaker is open
- The closing springs are charged
- The circuit breaker is not locked/interlocked in open position
- There is no standing closing order
- There is no standing opening order

Both contacts are available in a 1 NO configuration.

Electrical characteristics

AC ratings		DC ratings	
Voltage	**Amps**	**Voltage**	**Amps**
250V	AC21-6A	125V	DC21-0,4A
		250V	DC21-0,2A

Minimum operating current 0.16 A at 5V DC

Operations counter

A simple and easy to install mechanical device that displays an accurate and cumulative record of the number of closing operations of the EntelliGuard Air Circuit Breaker in which it is installed.

The mechanical and electrical life span of the breaker can be extended by limited periodic maintenance. The counter contains information that can assist in determining when the breaker requires servicing.

Terminal block

Breakers in fixed pattern, cassettes and breakers in draw-out mode are always supplied with an auxiliary connection block (terminal B and C).



When the number of factory installed accessories exceed, the available number of connection points needed, a 3rd connection block is added (terminal A) accordingly.
For connections please refer page 51.

IP54 cover

All Air Circuit Breakers are supplied with a door flange/door frame that allows the user to finish the door cut-out professionally, simultaneously providing a protection degree of IP31.

If a higher protection degree is required, an additional cover is available allowing IP54.



Rogowski coils

If the EntelliGuard trip unit is configured to allow earth/ground fault protection, an external neutral sensor can be required. Rogowski coils for this application are available as separate items and are supplied with a mounting kit. Rogowski are also required for sensing the set values and then allowing the trip unit to provide protection accordingly.

Hoisting / Lifting accessories

All EntelliGuard protection devices are equipped with a set of hoisting eyes. To use these hoisting eyes with standard lifting equipment, specifically designed adaptors are available.

Fascia pushbutton padlocking facilities

To prevent unauthorized access to both the ON and OFF push buttons on the breakers front fascia, a padlockable push button cover can be fixed to the breaker front fascia. 1 padlock of 5-8 mm can be used.

Breaker accessories

Cassette key lock facilities
The Air Circuit Breaker can be equipped with optional cassette key locks. The key lock system encompasses a device fitted to the cassette allowing the lock functionality. The device ensures that a draw out circuit breaker cannot be moved from the TEST or DISCONNECT position unless the key has been inserted and secured within the lock. The locks also prevent the breaker from (all positions) being swithced on.

Breaker key lock facilities
The Air Circuit Breaker can be equipped with a key lock system. The key lock system encompasses a device fitted in the front fascia allowing the locks to be fitted and to separate locks. These devices ensure that a circuit breaker cannot be closed unless the key has been inserted and secured within the lock.

Door interlock
A device designed to prevent the door of the equipment in which the breaker is installed to be opened when the Air Circuit Breaker is in connected position.
It is available in two executions; one for a door opening to the left and one to the right.

Cassette position indication contacts
A breaker in draw-out mode has a cassette that is used for mounting and connecting. The breaker, in its moving position mode, can be inserted into the cassette and by use of the racking handle it can be moved to one of three positions; which are described below.

Connected, test, disconnected or withdrawn
To indicate in which position the EntelliGuard breaker is located within the cassette, position indication contacts are available. The disconnected position is only being indicated when minimum isolating distances between contacts on both the main and auxiliary circuits have been achieved. Commonly referred to as carriage switches they are available as a factory mounted component or as a field mountable device.



Connections
The device is located in the left side base of the cassette substructure and can be accessed and connected directly.

Electrical characteristics

AC ratings		DC ratings	
Voltage	**Amps**	**Voltage**	**Amps**
250V	AC21-10A	125V	DC21-0,5A
		250V	DC21-0,25A

Spare parts for general use
The EntelliGuard™ Power Circuit breaker uses components that are designed to last the full life span of the device. However, certain components can be damaged or break during operational use. For these specific cases, the following spare parts are available:

Racking handle **(A)**
Breaker front cover **(B)**



Spare part for maintenace purposes
Air Circuit Breakers as the Entellliguard Power Circuit Breakers require periodic maintenance. Here, in some cases certain components critical to the devices functionality could need replacement.
Please contact our service department for specialist assistance in establishing which components need replacement and the physical replacement activities.
The following items are available:
- Arc Chutes **(A)**
- Fixed arcing Contacts **(B)**
- Cassette cluster contacts **(C)**
- Pliers to remove Cassette cluster contacts **(D)**









* Please contact our nearest authorised service centre for other available spare parts for EntelliGuard

Mechanical Interlocking of Multiple Breakers

Mechanically Interlocked Breakers
Many Low Voltage Installations have multiple power sources that are used in many different configurations.
The power sources are required to supply the installation simultaneously, alternatively or in a certain logical combinations of both.

The EntelliGuard™ Power Circuit Breaker can be used to protect these Power supplies and be electrically and mechanically interlocked to provide the necessary logic.
The mechanical interlocks are available for fixed and draw-out circuit breakers, enabling the direct interlocking of the breakers, mounted side by side or stacked.

The device has two parts; the first a kit customized for use with the breaker in fixed pattern or the cassette when a draw-out pattern is required (field mountable). Two or more specially designed field mountable cables available in lengths of 1,0; 1,6; 2,0; 2,5; 3,0; 3,5 and 4,0 meters being the second.

Any combination mode (fixed or draw-out), current rating, number of poles or envelope size can be interlocked. The interlocking systems are available in one configuration for 2 breakers and in three others for 3 breakers.

Two Breaker Interlock
Interlock type A in which one of the two breakers (B1 or B2) can be switched ON. Each breaker must be equipped with a factory mounted interlock type A. Two cables are needed.



Three Breaker Interlock type B
Interlock type B in which one of the three breakers (B1, B2 or B3) can be switched ON. Each breaker must be equipped with a factory mounted interlock type B. Six cables are needed.



Three Breaker Interlock type C
Interlock type C in which one or two of the three breakers can be switched ON in accordance with the inserted diagram. Each breaker must be equipped with a factory mounted interlock type C. Six cables are needed.



B1	B2	B3
0	0	0
I	0	0
0	0	I
0	I	0
I	I	0
0	I	I
I	0	I

Three Breaker Interlock type D
Interlock type D in which one or two of the three breakers can be switched ON in accordance with the inserted diagram. Breakers B1 & B3 must be equipped with a factory mounted interlock type A and B2 with a interlock type D. Four cables are needed.



B1	B2	B3
0	0	0
I	0	0
0	0	I
I	0	I
0	I	0

Breaker connection scheme

Standard connection scheme for terminal Block B



Optional connection scheme for terminal Block B



Standard connection scheme for terminal Block C
(when 3 sets of auxiliary contact are installed contacts 41 and 42 are not present)



Connection scheme for terminal Block D
(Located on the side plate of the cassette. Depicted carriage switches scheme is of the two switch per position type)



Index

Trip unit		Indication (ct'd)		Abbreviations	
24V+/24V-	Auxiliary power supply to trip unit	LP5	Breaker ready to close	CC	Close coil
N-RC	Neutral rogowski coil	LP6	Disconnected position	ST	Shunt release
		LP7	Test position	UVR	Under voltage release
Indication		LP8	Connected position	SPR	Spring change status
LP1	Spring charge status			RTC	Ready to close status
LP2	Breaker open			M	Motor operator
LP3	Breaker closed			BAT	Bell alarm trip
LP4	Fault				

Notes

Application Guide

D.2 Handling, Mounting & Connecting
D.3 Heat Dissipation, Watt loss & Current Ratings at temperatures >50°C
D.4 Selectivity/Discrimination, general rules
D.6 Protection of standard circuits
D.7 Protection of Generator sets, Motor, Capacitor banks and Transformers
D.7 Use of EntelliGuard Breakers in Automatic Power Transfer Systems (ATS)
D.8 Environmental considerations

Handling, mounting and connecting

Clearance distances

A modern circuit breaker is designed to interrupt high short-circuit currents in a very limited time frame. In doing so the breaker vents gas and a limited amount of conductive fragments.

EntelliGuard Air Circuit Breakers have been designed to limit the venting phenomenon to a minimum, but certain clearances do need to be taken into account as indicated in the front and side views.

The maintenance of the fixed pattern devices requires access to the contacts and the removal of the arc chutes. A certain distance needs to be left above the breaker to allow for this as indicated in the front and side views.

Minimum clearance distances on fixed pattern breaker from housing to:		
	Metal parts	Insulated parts
A(1)	160	160
B1	30	30
B2	30	30
Minimum clearance distances from draw-out cassette housing to:		
	Metal parts	Insulated parts
A(2)	0	0
B1	30	30
B2	30	30

(1) Dimension allows for field arc chute replacements

(2) With cassette top covers; distance without these parts 160mm

Handling

EntelliGuard Breakers in the fixed pattern and as draw-out portion have two retractable lifting eyes. One of these is located on the breaker right hand side and second on the left hand side (please see sketch).
The cassettes have four re-enforced tilting points with M10 screw thread.

Recommended connection cross sections

The adjacent table indicates the recommended bus bar dimensions to be used in connecting the EntelliGuard Air Circuit Breaker.

Front view fixed or draw-out pattern



Side view fixed pattern



Recommended copper busbar sizes (per phase)

Envelope	Rating (A)	Horizontal and flat/front termination	Vertical termination
1	630	2 x 50 x 5	1 x 100 x 5
	800	2 x 50 x 5	1 x 100 x 5
	1000	2 x 60 x 5	2 x 100 x 5
	1250	2 x 50 x 10	2 x 80 x 5
	1600	2 x 50 x 10	2 x 100 x 5
	2000	3 x 50 x 10	3 x 100 x 5
	2500	N/A	4 x 100 x 5
2	2000	3 x 50 x 10	3 x 100 x 5
	2500	4 x 50 x 10	4 x 100 x 5
	3200	4 x 100 x 10	4 x 100 x 10
	4000	(1)	4 x 100 x 10 + 1 x 100 x 5

(1) Consider vertical configuration. No horizontal configuration available.

Recommended aluminium busbar sizes (per phase)

Envelope	Rating (A)	Horizontal termination	Vertical termination
1	400	2 x 40 x 8	2 x 40 x 8
	630	2 x 40 x 8	2 x 40 x 8
	800	2 x 50 x 8	2 x 50 x 8
	1000	2 x 50 x 10	2 x 50 x 10
	1250	2 x 63 x 12	2 x 63 x 12
	1600	4 x 50 x 8	4 x 50 x 8
	2000	(4)	3 x 100 x 10
	2500	(4)	4 x 100 x 10
2	2000	3 x 100 x 10	3 x 100 x 10
	2500	4 x 100 x 10	4 x 100 x 10
	3200	(4)	4 x 150 x 10
	4000	(4)	5 x 150 x 10

(3) With specifically designed Aluminium connection kit; please contact us.

(4) Consider vertical configuration. No horizontal configuration available.

Heat dissipation, Watt loss and current ratings at temperatures >50°C

Standards
The standard for low voltage equipment is defined in the EN 60439-1, the EN 50298 and the IEC 60890. These provide a theoretical method to calculate the temperature rise within an enclosure. The main element in these calculations is the power dissipation of the equipment installed. By totalizing this value for all the installed devices, connections, cables and busbars, it is possible to calculate the temperature rise within the enclosure. For normal applications a temperature rise within the enclosure of 50° C is assumed.

Use
An enclosure manufacturer can provide the exact data on the allowable power dissipation within a certain enclosure. The values depend on the enclosure type, the ventilation it offers and where the components are located within this enclosure.

EntelliGuard Air Circuit Breakers
The devices have been designed to offer the lowest, feasible heat dissipation value and the highest possible current ratings when enclosed. The tables here indicate the heat dissipation values and current ratings at temperatures within the direct vicinity of the breaker in free air.
The values apply for breakers used with rear connections and the preferred vertical busbars. The recommended connection cross sections can be found on page D.2

EntelliGuard L type	Envelope	In in A	Power loss at In per pole in Watts		Temperature in the direct environment of the EntelliGuard									
					≤50°C	55°C	60°C	65°C	70°C	≤50°C	55°C	60°C	65°C	70°C
			Fixed breaker	Drawout breaker	Maximum user Current Ie in A Vertical connection mode: Fixed pattern					Maximum user Current Ie in A Vertical connection mode: Draw out pattern				
LG04S	1	400	4,60	8,80	400	400	400	400	400	400	400	400	400	400
LG04N - LG04R	1	400	2,40	4,80	400	400	400	400	400	400	400	400	400	400
LG07S	1	630	11,80	21,80	630	630	630	630	630	630	630	630	630	630
LG07N - LG07R	1	630	6,00	11,90	630	630	630	630	630	630	630	630	630	630
LG08S	1	800	19,20	35,20	800	800	800	800	800	800	800	800	800	800
LG08N - LG08R	1	800	9,60	19,20	800	800	800	800	800	800	800	800	800	800
LG10S	1	1000	30,00	55,00	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000
LG10N - LG10R	1	1000	15,00	30,00	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000
LG13S	1	1250	46,90	85,90	1250	1250	1250	1250	1250	1250	1250	1250	1250	1250
LG13N - LG13R	1	1250	23,40	46,90	1250	1250	1250	1250	1250	1250	1250	1250	1250	1250
LG16S	1	1600	66,60	128,00	1600	1600	1600	1600	1600	1600	1600	1500	1400	1350
LG16N - LG16R	1	1600	38,40	76,80	1600	1600	1600	1600	1600	1600	1600	1600	1600	1600
LG20S & N - LJ20R	1	2000	60,00	120,00	2000	2000	2000	2000	2000	2000	2000	2000	2000	2000
LG25S & N - LJ25R	1	2500	93,80	187,00	2500	2500	2500	2500	2500	2500	2450	2232	2100	2000
LG20, C & D - LJ20C	2	2000	60,00	120,00	2000	2000	2000	2000	2000	2000	2000	2000	2000	2000
LG25, C & D - LJ25C	2	2500	93,80	187,00	2500	2500	2500	2500	2500	2500	2500	2500	2500	2500
LG32, C & D - LJ32C	2	3200	81,90	184,30	3200	3200	3100	3050	3000	3200	3200	3100	3050	3000
LG40, C & D - LJ40C	2	4000	128,00	256,00	4000	3750	3500	3350	3200	4000	3750	3500	3350	3200

EntelliGuard L type	Envelope	In in A	Power loss at In per pole in Watts		Temperature in the direct environment of the EntelliGuard									
					≤50°C	55°C	60°C	65°C	70°C	≤50°C	55°C	60°C	65°C	70°C
			Fixed breaker	Drawout breaker	Maximum user Current Ie in A Horizontal connection mode: Fixed pattern					Maximum user Current Ie in A Horizontal connection mode: Draw out pattern				
LG04S	1	400	4,60	8,80	400	400	400	400	400	400	400	400	400	400
LG04N - LG04R	1	400	2,40	4,80	400	400	400	400	400	400	400	400	400	400
LG07S	1	630	11,80	21,80	630	630	630	630	630	630	630	630	630	630
LG07N - LG07R	1	630	6,00	11,90	630	630	630	630	630	630	630	630	630	630
LG08S	1	800	19,20	35,20	800	800	800	800	800	800	800	800	800	800
LG08N - LG08R	1	800	9,60	19,20	800	800	800	800	800	800	800	800	800	800
LG10S	1	1000	30,00	55,00	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000
LG10N - LG10R	1	1000	15,00	30,00	1000	1000	1000	1000	1000	1000	1000	1000	1000	1000
LG13S	1	1250	46,90	85,90	1250	1250	1250	1250	1250	1250	1250	1250	1250	1250
LG13N - LG13R	1	1250	23,40	46,90	1250	1250	1250	1250	1250	1250	1250	1250	1250	1250
LG16S	1	1600	66,60	128,00	1600	1500	1450	1400	1350	1600	1500	1450	1400	1350
LG16N - LG16R	1	1600	38,40	76,80	1600	1600	1600	1600	1600	1600	1600	1600	1600	1600
LG20S & N - LJ20R	1	2000	60,00	120,00	2000	2000	2000	2000	2000	2000	2000	2000	1900	1800
LG25S & N - LJ25R	1	2500	93,80	187,00	2500	2450	2232	2100	2000					
LG20, C & D - LJ20C	2	2000	60,00	120,00	2000	2000	2000	2000	2000	2000	2000	2000	2000	2000
LG25, C & D - LJ25C	2	2500	93,80	187,00	2500	2500	2500	2500	2500	2500	2500	2500	2500	2500
LG32, C & D - LJ32C	2	3200	81,90	184,30	3200	3200	3100	3050	3000	3200	2800	2700	2650	2500

Selectivity / Discrimination

Selectivity / Discrimination
In a low voltage distribution network it is necessary that during a fault, the protection device nearest to the fault reacts whilst all others remain closed.

This capability is called discrimination or selectivity.

If this requirement is not met a fault in one arm of the distribution system could cause a number of upstream protection devices to react and open. A relatively minor fault in one arm of a complete distribution will then cause a power interruption across a major part of the installation.

EntelliGuard Air Circuit Breakers
A combination of the high precision and multiple bands of the EntelliGuard Electronic Trip Unit allow full selectivity to be achieved between closely rated devices over multiple levels.

The table included here indicates the recommended settings of the upstream EntelliGuard Breaker as a a ratio to that of the downstream protection devices.

A second table on page 45 indicates the discrimination/ selectivity that can be achieved with these settings.
The tables can replace the complex and time consuming method of comparing multiple time current curves across many levels.

Downstream device *Record Plus*	Trip Unit	Setting denomination	Settings determining delectivity	Recommended EntelliGuard settings Ir or Ie setting ratio	LTDB setting band	Ist setting ratio	STDB setting band	I setting
FD and FE frame	LTMD	Ir	Ratio and Band	1.6 x	C22			
		Im	Ratio and Band			1.6 x	Band 2	*Minimum setting 5kA -FD160, 7kA - FE160, 9kA - FE250 or I = 'OFF'*
FD and FE frame	GTM	Ir	Ratio and Band	1.6 x	C22			
		Im	Ratio and Band			1.6 x	Band 2	
FE frame PremEon S	SMR PremEon S	Ir	Ratio and Band	1.3 x				
		LTD Motor	Band		C14			
		Ist	Ratio and Band			1.35 x	Band 2	
FG frame PremEon S	SMR1	Ir	Ratio and Band	1.3 x				
		LTD Motor	Band		C14			
		Ist	Ratio and Band			1.35 x	Band 3	
FG frame	SMR2	Ir	Ratio	1.3 x				*Minimum setting 14kA -FG400, 18kA - FG630 or use ZSI or I = 'OFF'*
		LTD cl.1.25	Band		C3			
		LTD cl. 2.5	Band		C5			
		LTD cl. 5	Band		C8			
		LTD cl.10	Band		C12			
		LTD cl.20	Band		C16			
		LTD cl.30	Band		C18			
		Ist	Ratio			1.35 x		
		STD=420ms	Band				Band 13	
		STD=310ms	Band				Band 11	
		STD=210ms	Band				Band 9	
		STD=120ms	Band				Band 6	
		STD=40ms	Band				Band 3	
FK frame	SMR1e	Ir	Ratio and Band	1.4 x	C8			*Minimum setting 18kA -FK800 20kA - FK1000 20kA - FK1250 28kA - FK1600 or use ZSI or I = 'OFF'*
		Ist	Ratio			1.35 x		
		STD	Band				Band 7	
FK frame	SMR1s	Ir	Ratio	1.4 x				
		LTD cl. 5	Band		C8			
		LTD cl.10	Band		C12			
		LTD cl.20	Band		C19			
		LTD cl.30	Band		C22			
		Ist	Ratio					
		STD=300ms	Band				Band 12	
		STD=200ms	Band				Band 10	
		STD=100ms	Band				Band 7	
EntelliGuard	GT-L, -E, -S '-N, -H, -HE	Ir	Ratio	1.25 x				*Use ZSI or I = 'OFF'*
		LTD class	Band		2 higher			
		Ist	Ratio			1.25 x		
		STD band min, until 11	Band				2 higher	
		STD band ≤12					1 higher	
Industrial fuses GL/Gg type	----	Current rating	Ratio and Band	2 x	F20	ST = 8 x Ir, STDB band 5 and I = 12 x Ie		

Selectivity / Discrimination table

Downsteam Device	Trip Unit	Upstream EntelliGuard device and Selectivity limit I_s (1)				
		GG04S to GG20S	GG04N to GG20N	LG04N to LG25N	LG20C to LG40C	GG25N to GG40N
Elfa Plus MCB's EP30,45, 60,100&250, CP30,45&60, DME60, DPE100, DP(A)60, DP(A)100 & DPT100	All	T		T	T	T
Elfa Plus MCB's HTI & S90 C curve	All	T		T	T	T
Surion Manul Motor starters GPS1BS <=10A GPS1MH<=12.5A GPS2BS 10A, GPS2MH 10A	All	T		T	T	T
Surion Manul Motor starters GPS1BS, GPS1MS 12.5kA, GPS1MH > 12.5A, GPS2MH >10A	All	T		T	T	T
Surion Manul Motor starters GPS1BS, GPS1MS >=16A, GPS2BS >10A	All	T		T	T	T
Record Plus						
FD& FE frame C, E, V, S tiers	All	T		T	T	T
FD& FE frame N tier	All	T		T	T	T
FD& FE frame H tier	All	T		T	T	T
FD& FE frame L tier	All	T		T	T	T
FG frame N tier	All	T		T	T	T
FG frame H tier	All	T		T	T	T
FG frame L tier	All	T		T	T	T
FK frame N tier	All	T		T	T	T
FK frame H tier	All	T		T	T	T
FK frame L tier	All	T		T	T	T
EntelliGuard L						
LG04S to LG25S	All	50kA		T	50kA	T
LG04N to LG25N	All	50kA		65kA	50kA	65kA
LG20C to LG40C	All	50kA		T	50kA	T
LG20D to LG40D	All	50kA		65kA	50kA	65kA
Industrial fuses GL/Gg type	-	T		T	T	T

(1) T = Full discrimination until the Icu of the downstream or upstream device. (the lowest of the two)
Selectivity is also present with upstream EntelliGuard G devices type GG04E to GG40E, GG(GH)25H to GG(GH)40H , GG(GH)25M to GG(GH)40M, GG32G to GG40G, GG40M to GG64M and GG40L to GG64L.

Protection of standard circuits

Protection of standard circuits
Protection devices as the EntelliGuard Air Circuit breaker are used in a wide variety of environments to protect conductors, equipment and devices in low voltage distribution circuits. To use this product to its full potential, it is necessary to verify that it functions correctly in the environment in which it is used, and that it meets the electrotechnical requirements of the circuit it protects.

Environment
EntelliGuard will function well in almost any industrial environment and fully complies with the environmental requirements of the relevant EN60947-2 standard.

Maximum short-circuit current
Each protective device must be capable of interrupting the maximum short-circuit current at the point where it is installed (see HD384 standard). The interruption ratings (Breaking Capacities) of the EntelliGuard circuit breaker can be found on page 3 of this catalogue.

Design current of a circuit
The equipment and devices in an electrical circuit determine its current load or design current (Ib).
A circuit breaker's overload or Ir setting is normally adjusted to a value equal to the design current.

Weakest short-circuit current in a circuit
On a short-circuit event, the total circuit impedance determines both the MAXIMUM and WEAKEST short-circuit current that can flow in the circuit.

For the weakest short circuit current, it is necessary to establish if the protection device trips before the electrical conductors reach their maximum temperature, this for operating times of 0.1 to 5 seconds.

Fault currents
In the 2005 edition of the IEC60364-4-41 the general terminology, 'Protection against Electrical shock' has been adapted whilst two new terms have been introduced:

1) Protection under normal conditions now designated:
   Basic protection

2) Protection under fault conditions now designated:
   Fault protection

Fault protection being provided by protective equipotential bonding and automatic disconnection of the supply. Under fault conditions, depending on the network an interruption time of 5 seconds (TN) or 1 second is required (TT) for circuits with a rating >32A. Depending on the configuration of the earthing system, the 1 and 5 second disconnection time is also required for interruption of a second fault in IT systems.

EntelliGuard Air Circuit breakers
To protect standard circuits, the breakers are equipped with a number of protection devices.

Overload protection device
First highly accurate menu driven overload protection device that has an adjustment range of 0.4 to 1 x the breaker rating. in thirteen steps.
This device is normally set to a value that is equal or closely matches the design current (Ib).

Timed short-circuit protection device
Set as a multiple of the overload adjustment. This device offers a broad adjustment range of 1.5 to 12.
The setting of this device depends on several parameters:
- inrush characteristics of the protected devices
- protection against the **weakest short-circuit current**
- fault currents to earth

17 narrow and accurate time bands allow the EntelliGuard Air Circuit Breaker to interrupt a fault within the timing required by the standards. to offer selectivity across multiple levels and allow the user to take inrush currents into account.

Ground fault protection
It is possible to combine two devices to detect **fault currents** to earth. They can be set as a multiple of the value of the current sensors mounted in the breaker and have a broad adjustment range of 0.2 to 1 times the breaker rating.

The first is a residual device that takes the sum of the current in three phases and neutral. If this is no longer equal to zero it sends an alarm or trips the breaker.

The second allows the user to measure the return current running between the earth leg and neutral. On detecting a fault to earth, the device sends an alarm, or trips the breaker.

14 narrow and accurate time bands allow the EntelliGuard Air Circuit Breaker to interrupt a fault within the timing required by the standards and offer selectivity across multiple levels.

Instantaneous short-circuit protection
Set as a multiple of the primary overload adjustment Ie this device offers a broad adjustment range of 2 to 15.

This device is normally used to limit the time that higher short-circuit currents can run in the protected circuit. Whilst the timed short-circuit protection device waits for a set time, the instantaneous device immediately trips the breaker once the set value is reached.

The device used in the EntelliGuard Air Circuit Breaker maintains selectivity by only reacting to the 2nd half wave of a short-circuit current and uniquely allows the use of the 'Zone Selective Interlock' feature.

Applications

Protection of generator sets, motors, capacitor banks and transformers
Use of EntelliGuard Breakers in Automatic Power Transfer Systems (ATS)

Introduction
The electronic trip unit used in the EntelliGuard Air Circuit Breaker offers many additional protection devices. Here number of the possible applications of these devices are described briefly.

Protection of generator sets
The overload and short-circuit devices used to protect a generator need to react quicker and at lower current levels than those used to protect other devices.

After establishing, the capabilities of the generator are set under overload and short-circuit conditions. The protection devices need to be adjusted accordingly.

On a Air Circuit Breaker use of the 'faster' overload protection bands (LTDB set between minimum and the C6 band) and a low setting of the timed short-circuit protection (2.5 x Ir) is recommended. The optional 3 phase undervoltage protection available in the GT-H trip unit can also be considered.

Protection of motors
On starting, electrical motors draw more current than when running under normal conditions. These starting currents differ strongly per type and should not cause tripping of the device protecting the circuit.
The IEC60947-4 has defined four different 'Operational' or 'Trip' classes:

Trip class	Required tripping times at		
	1.2 x In	1.5 x In	7.2 x In
10A	t < 2 hours	t < 2 min.	2 ≤ t < 10 sec.
10	t < 2 hours	t < 4 min.	4 ≤ t ≤ 10 sec.
20	t < 2 hours	t < 8 min.	6 ≤ t ≤ 20 sec.
30	t < 2 hours	t < 12 min.	9 ≤ t ≤ 30 sec.

This table is in some cases extended to include a 'Trip class 40' (assumed to be a 15-40 second band at 7.2 x In).
On a Air Circuit Breaker, use of the 'slower' protection bands that closely match the indicated classes is recommended (LTDB set between the C8 to the C22 band).

Switching on a motor also produces a high but very short inrush peak current which could activate the short-circuit protection of a breaker and cause unexpected tripping. Here the timed short-circuit device of a Air Circuit Breaker must be set to at least 12 x Ir with a time delay of 50 milliseconds (STDB band 3). If an instantaneous protection device is present and switched on, a setting of at least 12 x Ie is recommended.

After an overload event, if motor and wiring are still warm, a immediate re-energization of the electrical circuit could result in damage of the electrical circuit and the motor.

The overload protection device must incorporate a thermal memory device that prevents re-energization before a certain cooling time has elapsed.

Remark
Furthermore, the prevention of anomalies as the motor losing a phase or a motor with blocked rotor need to be prevented and require additional protection devices.
Next to the 'Standard' protection devices, the EntelliGuard Electronic Trip Unit has a thermal memory function, an optional 3 phase undervoltage relay and current unbalance device, thus providing comprehensive motor protection.

Protection of capacitor banks
Air Circuit Breakers are designed to offer high making and breaking capacities under adverse conditions: The switching of capacitor banks has little to no effect on the breaker, its characteristics as a protective device or on its lifespan.

However the current flowing in the circuit can trip a circuit breaker and a capacitor load does display certain anomalies. Here the current flowing in the circuit cannot be assumed to be the calculated capacitor current only. The effective current value is higher due to harmonic content (normally assumed as 30%) and an allowance must be made for tolerances in the capacitance of the units (10%). The protection devices of the Air Circuit Breaker must be set accordingly.

Protection of LV / HV transformers
Transformers generally produce a very high inrush current. The crest values of the first half cycle may reach values of 15 to 25 times the normal rated current.
Manufacturers data and tests have indicated that, a protection device feeding a transformer must be capable of carrying the following current values without tripping.

Transformer value	Crest inrush values		
	1st period	2nd period	After 3 periods
< 50 kvA	25 x In	12 x In	5 x In
≥ 50 kvA	15 x In	8 x In	3,5 x In

It is recommended that the timed short-circuit device of a Air Circuit Breaker is set to at least 8 x Ir with a time delay of 30 milliseconds (STDB band 1). If an instantaneous protection device is present, the use of the extended adjustment range with setting of 20 x Ie is advisable (=15 x In plus tolerances).

Automatic Transfer Systems (ATS)
EntelliGuard Air Circuit Breakers are available with mechanical interlocks for 2 to 3 breakers and have a unique electrical network interlocking system allowing the user to completely lock out one or more breakers.
The logical transfer of power from one source to another is thus strongly simplified whilst the high speed electrical closing and opening of the device allows their use in synchronization applications.

Here, numerous other EntelliGuard protection features can be used, one of which being the Electronic Trip unit 3 phase undervoltage release. This is to establish if voltage on a certain power source is present and if a generator set has reached its nominal voltage.

Environmental considerations

Ambient temperature
EntelliGuard Air Circuit Breakers are designed to operate normally at temperatures of -5 degrees to +70°C. They can be used at temperatures down to -20°C with a reduced electrical and mechanical life span.

To prevent materials from reaching temperatures that have an adverse effect on their electrical and/or mechanical properties, de-rating factors must be applied when the device is used in ambient temperatures higher than 50°C.

Storage temperature
Air Circuit Breakers can be stored at non operational temperatures of -40° degrees up to +70°C.

Influence of altitude
Up to an altitude of 2000m above sea level no de-rating of breaker rated current or rated voltage is applicable. For altitudes above 2000m the following de-rating factors apply:

Alttitude	Altitude correction factors		
	≤ 2000M	2500M	4000M
Voltage (Ue)	1	0.95	0.80
Current (In)	1	0.99	0.96

Other atmospheric conditions
The EntelliGuard breaker line has been designed to operate at the temperatures and relative humidities defined in the EN 60947 clause 6.1.3.1.

They also meet the requirements of the following standards:

IEC 68-2-1	Cold
IEC 68-2-2	Dry heat
IEC 68-2-3	Damp heat
IEC 68-2-11	Salt
IEC 68-2-14	Change of temperature
IEC 68-2-30	Damp heat cyclic
IEC 721	Climatic

Vibration
Air Circuit Breakers meet the vibration requirements of the following standards:

IEC 68-2-6	Vibration

Other
All EntelliGuard devices meet the existing European ROHS directive.

Electromagnetic compatibility
The EntelliGuard Air Circuit Breaker and its electronic trip unit meet the most stringent requirements of the EN 60947-2 and IEC 1004 standard. The following tests have been successfully completed.

Harmonics, current dips, interruptions and power frequency variations
All EN 60947 annex F, sub-clause F4.1 through 3 requirements covering non sinusoidal currents resulting from harmonics are met. Testing covering the following elements:
- wave forms consisting of a fundamental + 3rd harmonic component at 50 and 60Hz
- wave forms consisting of a fundamental + 5th harmonic component at 50 and 60Hz
- composite wave forms with a fundamental component + a 3rd, 5th and 7th harmonic at 50 and 60Hz
- current dips and current interruptions
- frequency variations from 45 to 65Hz in 1 Hz steps

Electrostatic discharge
EN 60947 annex F, sub-clause F and the IEC 1004-2
- passed level 4, air discharge 15kV

Radiated, radio frequency, electromagnetic field immunity test
EN 60947-2 annex F, sub-clause F7 and the IEC 1000-4-3 (basic standard)
- passed higher than level 4 field strength 30V/m

Electrical fast transient / Burst
EN 60947-2 annex F, sub-clause F5 and the IEC 1000-4-4 (basic standard)
- passed level 4 burst peak voltage 4kV

Surge immunity test
EN 60947-2 annex F, sub-clause F5 and the IEC 1000-4-5 (basic standard)
- passed level 4 voltage 1.2µs/50µs 6kV; current 8µs/20µs 3kA

Dry heat test
EN 60947-2 annex F, sub-clause F8
- passed all test requirements

Thermal shock test
EN 60947-2 annex F, sub-clause F9
- no nuisance tripping within the 28-day temperature cycles

Notes

Notes

Dimensional Drawings

E.2 Envelope 1 Fixed type

E.3 Envelope 1 Draw out type, Univeral connection pads

E.4 Envelope 1 Draw out type, Horizontal connections

E.5 Envelope 2 Fixed type

E.6 Envelope 2 Draw out type, Univeral connection pads

E.7 Envelope 2 Draw out type, Horizontal connections

E.8 Envelope 2 Draw out type 4000A, Vertical connection pads

E.9 Alternate connection modes

E.10 Ip54 Flange, Time Delay Module UVR, 24V power supply

E.11 Rogowski sensors, Door interlock system

E.12 Interlocking with cable systems; 2 way

E.13 Interlocking with cable systems; 3 way

Envelope 1 - Fixed Pattern

Front view 4pole



Front view 3pole



Side view



Top view 4pole



Door Cut-out



Top view 3pole



Breaker type	A	B minimum	C
Envelope 1 3 pole	20,0	55,0	0,0
Envelope 1 4 pole	20,0	55,0	-49,5

Standard Connection pads

S type <=1600A



N & R types 400-2500A
S type 2000 & 2500A



Remarks

1. 6 mounting holes of Ø 9,5mm
2. Please refer to section C for clearance distances

Envelope 1 - Draw-out Pattern: Universal connection pads

Front view 4pole



Front view 3pole



Side view



Bottom view 4pole



Door Cut-out



Bottom view 3pole



Breaker type	A	B minimum	C
Envelope 1 3 pole	-7,0	60,0	0,0
Envelope 1 4 pole	-7,0	60,0	-49,5

Remarks

1. **6 mounting holes of Ø 9,5mm**
2. **Please refer to section C for clearance distances**

Universal Connection pads Mounted Horizontally or Vertically



S type <=1600A

N types 400-2500A
S type 2000 & 2500A

Universal Connection pads Details



Valid for All types

S type <=1600A

N & R types 400-2500A
S type 2000 & 2500A

Envelope 1 - Draw-out Pattern: Horizontal connection pads, applicable up to 2000A

Front view 4pole



Front view 3pole



Side view



Bottom view 4pole



Door Cut-out



Top view 3pole



Breaker type	A	B minimum	C
Envelope 1 3 pole	-7,0	60,0	0,0
Envelope 1 4 pole	-7,0	60,0	-49,5

Remarks

1. **6 mounting holes of Ø 9,5mm**
2. **Please refer to section C for clearance distances**

Universal Connection pads Mounted Horizontally or Vertically



S type <=1250A



S type 1600A



N & R types 400-2000A
S type 2000 A

Envelope 2 - Fixed Pattern

Front view 4pole



Front view 3pole



Side view



Top view 4pole



Door Cut-out



Top view 3pole



Breaker type	A	B minimum	C
Envelope 2 3 pole	80,0	115,0	15,5
Envelope 2 4 pole	80,0	115,0	-49,5

Standard Connection pads



Remarks

1. 6 mounting holes of Ø 9,5mm
2. Please refer to section C for clearance distances

Envelope 2 - Draw-out Pattern: Univeral connection pads

Front view 4pole



Front view 3pole



Side view



Bottom view 4pole



Door Cut-out



Bottom view 3pole



Breaker type	A	B minimum	C
Envelope 2 3 pole	53,0	125,0	15,5
Envelope 2 4 pole	53,0	125,0	-49,5

Universal Connection pads
Vertical or Horizontal max. 3200A



Vertical Connection pads
4000A rating



Remarks

1. 6 mounting holes of Ø 9,5mm
2. Please refer to section C for clearance distances

Envelope 2 - Draw-out Pattern: Horizontal connection pads, applicable upto 3200A

Front view 4pole



Front view 3pole



Side view



Bottom view 4pole



Door Cut-out



Bottom view 3pole



Breaker type	A	B minimum	C
Envelope 2 3 pole	53,0	125,0	15,5
Envelope 2 4 pole	53,0	125,0	-49,5

Connection pads details



Remarks

1. 6 mounting holes of Ø 9,5mm
2. Please refer to section C for clearance distances

Envelope 1 & 2 - Alternate Connection Modes

Fixed Rear Vertical Connection
Envelope 1 < = 1600A



Fixed Vertical Rear Connection
Envelope 2

MAX. 3200A



4000A



Details max. 3200A



Details max. 4000A



Fixed Rear Vertical Connection
Envelope 1 2000 & 2500A



Fixed Front Connection
Envelope 1 <= 1600A



Fixed Front Connection
Envelope 1 2000 & 2500A



Drawout Front Connection
Envelope 1 <=1600A



Drawout Front Connection
Envelope 1 2000 & 2500A



IP54 Flange, Time Delay Module UVR, 24V Power Supply

IP54 Flange



IP54 Flange drilling



Time delay Module (UVR)





External 24V DC power supply



Rogowski's & Door Interlock systems

Rogowski Coil external



Door Interlock system



Interlocking with Cable systems; 2 way

Fixed pattern 2-way cable interlock / Fixed pattern - Front/rear access



Draw-out 2-way cable interlock / Withdrawable pattern - Front/rear access



Interlocking with Cable systems; 3 way

Fixed pattern 3-way cable interlock / Fixed pattern - Front/rear access



Draw-out 3-way cable interlock / Withdrawable pattern - Front/rear access



Air Circuit Breakers Intro
Order Codes A
Electronic Trip Units B
Breaker Accessories C
Application Guide D
Dimensions E
Numerical index X

X.2 Numerical index by **reference number**
X.4 Numerical index by **catalogue number**

Ref. No.	Cat. No.	Page
407700	GM01024D	A.9
407701	GM01024DR	A.11
407706	GM01110D	A.9
407707	GM01110DR	A.11
407712	GM01120A	A.9
407713	GM01120AR	A.11
407714	GM01240A	A.9
407715	GM01240AR	A.11
407720	GM01220D	A.9
407721	GM01220DR	A.11
407770	GSTR024D	A.9
407771	GSTR024DR	A.11
407772	GSTR048	A.9
407773	GSTR048R	A.11
407776	GSTR120	A.9
407777	GSTR120R	A.11
407778	GSTR240	A.9
407779	GSTR240R	A.11
407782	GSTR400A	A.9
407783	GSTR400AR	A.11
407795	GUVT024D	A.9
407796	GSTR024DR	A.11
407797	GUVT048	A.9
407798	GSTR048R	A.11
407801	GUVT120	A.9
407802	GSTR120R	A.11
407803	GUVT240	A.9
407804	GSTR240R	A.11
407807	GUVT400A	A.9
407808	GSTR400AR	A.11
407818	GTDM120A	A.13
407819	GTDM120D	A.13
407820	GTDM240A	A.13
407821	GTDM240D	A.13
407824	GTDM400A	A.13
407860	GCCN024DR	A.11
407861	GCCN024D	A.9
407866	GCCN120R	A.11
407867	GCCN120	A.9
407868	GCCN240R	A.11
407869	GCCN240	A.9
407897	GRTC1	A.9
407985	GRON	A.11
407986	GPRO	A.11
407990	GCB1	A.13
407991	GCB2	A.13
407992	GCB3	A.13
407993	GCB4	A.13
407994	GCB5	A.13
407995	GCB6	A.13
407996	GCB7	A.13
407999	GTUTK20	A.13
408026	GDPRW	A.14
408033	GMCNR	A.11
408035	GMCN	A.9
408038	G54DR	A.14
408040	GPBD	A.13
408045	GLB1	A.14
408046	GTUS	A.13
408047	GUNI	A.14
408066	G32M4FFI	A.5
408067	G40M4FFI	A.5
408068	G32M6FFI	A.5
408069	G40M6FFI	A.5
408070	G32M4RVI	A.5
408071	G32M6RVI	A.5
408072	G40M4RVI	A.5
408074	G40M6RVI	A.5
408789	GAPU	A.13
444000	LG04S1	A.4
444001	LG07S1	A.4
444002	LG08S1	A.4
444003	LG10S1	A.4
444004	LG13S1	A.4
444005	LG16S1	A.4
444006	LG20S1	A.4
444007	LG25S1	A.4
444008	LG20C1	A.4
444009	LG25C1	A.4
444010	LG32C1	A.4
444011	LG40C1	A.4
444012	LG04N1	A.4
444013	LG07N1	A.4
444014	LG08N1	A.4
444015	LG10N1	A.4
444016	LG13N1	A.4
444017	LG16N1	A.4
444018	LG20N1	A.4
444019	LG25N1	A.4
444020	LG20D1	A.4
444021	LG25D1	A.4
444022	LG32D1	A.4
444023	LG40D1	A.4
444033	LG04S3	A.4
444034	LG07S3	A.4
444035	LG08S3	A.4
444036	LG10S3	A.4
444037	LG13S3	A.4
444038	LG16S3	A.4
444039	LG20S3	A.4
444040	LG25S3	A.4
444041	LG20C3	A.4
444042	LG25C3	A.4
444043	LG32C3	A.4
444044	LG40C3	A.4
444045	LG04N3	A.4
444046	LG07N3	A.4
444047	LG08N3	A.4
444048	LG10N3	A.4
444049	LG13N3	A.4
444050	LG16N3	A.4
444051	LG20N3	A.4
444052	LG25N3	A.4
444053	LG20D3	A.4
444054	LG25D3	A.4
444055	LG32D3	A.4
444056	LG40D3	A.4
444066	LG04S4	A.4
444067	LG07S4	A.4
444068	LG08S4	A.4
444069	LG10S4	A.4
444070	LG13S4	A.4
444071	LG16S4	A.4
444072	LG20S4	A.4
444073	LG25S4	A.4
444074	LG20C4	A.4
444075	LG25C4	A.4
444076	LG32C4	A.4
444077	LG40C4	A.4
444078	LG04N4	A.4
444079	LG07N4	A.4
444080	LG08N4	A.4
444081	LG10N4	A.4
444082	LG13N4	A.4
444083	LG16N4	A.4
444084	LG20N4	A.4
444085	LG25N4	A.4
444086	LG20D4	A.4
444087	LG25D4	A.4
444088	LG32D4	A.4
444089	LG40D4	A.4
444100	LG04S6	A.4
444101	LG07S6	A.4
444102	LG08S6	A.4
444103	LG10S6	A.4
444104	LG13S6	A.4
444105	LG16S6	A.4
444106	LG20S6	A.4
444107	LG25S6	A.4
444108	LG20C6	A.4
444109	LG25C6	A.4
444110	LG32C6	A.4
444111	LG40C6	A.4
444112	LG04N6	A.4
444113	LG07N6	A.4
444114	LG08N6	A.4
444115	LG10N6	A.4
444116	LG13N6	A.4
444117	LG16N6	A.4
444118	LG20N6	A.4
444119	LG25N6	A.4
444120	LG20D6	A.4
444121	LG25D6	A.4
444122	LG32D6	A.4
444123	LG40D6	A.4
444135	LJ04R1	A.6
444136	LJ07R1	A.6
444137	LJ08R1	A.6
444138	LJ10R1	A.6
444139	LJ13R1	A.6
444140	LJ16R1	A.6
444141	LJ20R1	A.6
444142	LJ25R1	A.6
444143	LJ20C1	A.6
444144	LJ25C1	A.6
444145	LJ32C1	A.6
444146	LJ40C1	A.6
444147	LJ04R3	A.6
444148	LJ07R3	A.6
444149	LJ08R3	A.6
444150	LJ10R3	A.6
444151	LJ13R3	A.6
444152	LJ16R3	A.6
444153	LJ20R3	A.6
444154	LJ25R3	A.6
444155	LJ20C3	A.6
444156	LJ25C3	A.6
444157	LJ32C3	A.6
444158	LJ40C3	A.6
444161	LJ04R4	A.6
444162	LJ07R4	A.6
444163	LJ08R4	A.6
444164	LJ10R4	A.6
444165	LJ13R4	A.6
444166	LJ16R4	A.6
444167	LJ20R4	A.6
444168	LJ25R4	A.6
444169	LJ20C4	A.6
444170	LJ25C4	A.6
444171	LJ32C4	A.6
444172	LJ40C4	A.6
444173	LJ04R6	A.6
444174	LJ07R6	A.6
444175	LJ08R6	A.6
444176	LJ10R6	A.6
444177	LJ13R6	A.6
444178	LJ16R6	A.6
444179	LJ20R6	A.6
444180	LJ25R6	A.6
444181	LJ20C6	A.6
444182	LJ25C6	A.6
444183	LJ32C6	A.6
444184	LJ40C6	A.6
444190	LM01024D	A.9
444191	LM01110D	A.9
444192	LM01220D	A.9
444193	LM01120A	A.9
444194	LM01240A	A.9
444195	LM01024DR	A.11
444196	LM01110DR	A.11
444197	LM01220DR	A.11
444198	LM01120AR	A.11
444199	LM01240AR	A.11
444200	LDPRF	A.14
444205	LAS3	A.9
444206	LAS4	A.9
444207	LBAT1	A.9
444208	LAS3R	A.11
444209	LAS4R	A.11
444210	LBAT1R	A.11
444211	LBPRO	A.9
444212	LBRON	A.9
444214	LBCA9	A.9
444215	LCPRO	A.9
444216	LCRON	A.9
444221	LI2FAD	A.10
444222	LI2WAD	A.10
444223	LI3FB	A.10
444224	LI3WB	A.10
444225	LI3FC	A.10
444226	LI3WC	A.10
444227	LI3FDT	A.10
444228	LI3WDT	A.10
444230	LCPS1	A.9
444231	LCPS1R	A.11
444232	LCPS2	A.9
444233	LCPS2R	A.11
444240	L1LHD	A.13
444241	L1RHD	A.13
444242	L2LHD	A.13
444243	L2RHD	A.13
444246	LREPM	A.13
444260	LTG00K1XXSF	A.8
444261	LTG00K2XXSF	A.8
444262	LTG00K9XXSF	A.8
444263	LTG00K3XXS	A.8
444270	LG13S2FM	A.5
444271	LG13S2UM	A.5
444272	LG13S2HM	A.5
444273	LG13S5FM	A.5
444274	LG13S5UM	A.5
444275	LG13S5HM	A.5
444276	LG16S2FM	A.5
444277	LG16S2UM	A.5
444278	LG16S2HM	A.5
444279	LG16S5FM	A.5
444280	LG16S5UM	A.5
444281	LG16S5HM	A.5
444282	LG25N2FM	A.5
444283	LG25N2UM	A.5
444284	LG20N2HM	A.5
444285	LG25N5FM	A.5
444286	LG25N5UM	A.5
444287	LG20N5HM	A.5
444288	LG32D2UM	A.5
444289	LG32D2HM	A.5
444290	LG32D5UM	A.5
444291	LG32D5HM	A.5
444292	LG40D2VM	A.5
444293	LG40D5VM	A.5
444300	LG13S2FR	A.12
444301	LG13N2UR	A.12
444302	LG13S2HR	A.12
444303	LG13S5FR	A.12
444304	LG13N5UR	A.12
444305	LG13S5HR	A.12
444306	LG16S2FR	A.12
444307	LG16N2UR	A.12
444308	LG16S2HR	A.12
444309	LG16S5FR	A.12
444310	LG16N5UR	A.12
444311	LG16S5HR	A.12
444312	LG25N2FR	A.12
444313	LG25N2UR	A.12
444314	LG20N2HR	A.12
444315	LG25N5FR	A.12
444316	LG25N5UR	A.12
444317	LG20N5HR	A.12
444318	LG32D2UR	A.12
444319	LG32D2HR	A.12
444320	LG32D5UR	A.12
444321	LG32D5HR	A.12
444322	LG40D2VR	A.12
444323	LG40D5VR	A.12
444404	L25DARC	A.14
444405	L13NCLS	A.14
444406	L16NCLS	A.14
444407	L25NCHT	A.14
444408	L25NCLS	A.14
444409	L40DCLS	A.14
444410	L40DARC	A.14
444411	L40DCHT	A.14
444412	LRHN	A.14
444413	LFAL1	A.14
444414	LFAL2	A.14
444415	LSDT	A.14
444420	L104NRC	A.8
444421	L106NRC	A.8
444422	L108NRC	A.8
444423	L110NRC	A.8
444424	L113NRC	A.8
444425	L116NRC	A.8
444426	L120NRC	A.8
444427	L220NRC	A.8
444428	L125NRC	A.8
444429	L225NRC	A.8
444430	L232NRC	A.8
444432	L240NRC	A.8
444440	L16S4FFI	A.5
444441	L16S4RVI	A.5
444442	L16S6FFI	A.5
444443	L16S6RVI	A.5
444444	L25N4FFI	A.5
444445	L25N4RVI	A.5
444446	L25N6FFI	A.5
444450	L1CTC1	A.12
444451	L1CTC3	A.12
444452	L2CTC1	A.12
444453	L2CTC3	A.12
444465	SMS31F16L16S	A.15
444466	SMS41F16L16S	A.15
444470	SMN31F16L16N	A.15
444471	SMN41F16L16N	A.15
444475	SMN31F25L25N	A.15
444476	SMN41F25L25N	A.15
444480	SMS31W12L13S	A.15
444481	SMS41W12L13S	A.15
444485	SMS31F16L16S	A.15
444486	SMS41F16L16S	A.15
444490	SMN31W16L16N	A.15
444491	SMN41W16L16N	A.15
444495	SMN31W25L25N	A.15
444496	SMN41W24L25N	A.15

Notes

Cat. No.	Ref. No.	Page
G32M4FFI	408066	A.5
G32M4RVI	408070	A.5
G32M6FFI	408068	A.5
G32M6RVI	408071	A.5
G40M4FFI	408067	A.5
G40M4RVI	408072	A.5
G40M6FFI	408069	A.5
G40M6RVI	408074	A.5
G54DR	408038	A.14
GAPU	408789	A.13
GCB1	407990	A.13
GCB2	407991	A.13
GCB3	407992	A.13
GCB4	407993	A.13
GCB5	407994	A.13
GCB6	407995	A.13
GCB7	407996	A.13
GCCN024D	407861	A.9
GCCN024DR	407860	A.11
GCCN120	407867	A.9
GCCN120R	407866	A.11
GCCN240	407869	A.9
GCCN240R	407868	A.11
GDPRW	408026	A.14
GLB1	408045	A.14
GM01024D	407700	A.9
GM01024DR	407701	A.11
GM01110D	407706	A.9
GM01110DR	407707	A.11
GM01120A	407712	A.9
GM01120AR	407713	A.11
GM01220D	407720	A.9
GM01220DR	407721	A.11
GM01240A	407714	A.9
GM01240AR	407715	A.11
GMCN	408035	A.9
GMCNR	408033	A.11
GPBD	408040	A.13
GPRO	407986	A.11
GRON	407985	A.11
GRTC1	407897	A.9
GSTR024D	407770	A.9
GSTR024DR	407796	A.11
GSTR048	407772	A.9
GSTR048R	407798	A.11
GSTR120	407776	A.9
GSTR120R	407802	A.11
GSTR240	407778	A.9
GSTR240R	407804	A.11
GSTR400A	407782	A.9
GSTR400AR	407808	A.11
GTDM120A	407818	A.13
GTDM120D	407819	A.13
GTDM240A	407820	A.13
GTDM240D	407821	A.13
GTDM400A	407824	A.13
GTUS	408046	A.13
GTUTK20	407999	A.13
GUNI	408047	A.14
GUVT024D	407795	A.9
GUVT048	407797	A.9
GUVT120	407801	A.9
GUVT240	407803	A.9
GUVT400A	407807	A.9
L104NRC	444420	A.8
L106NRC	444421	A.8
L108NRC	444422	A.8
L110NRC	444423	A.8
L113NRC	444424	A.8
L116NRC	444425	A.8
L120NRC	444426	A.8
L125NRC	444428	A.8
L13NCLS	444405	A.14
L16NCLS	444406	A.14
L16S4FFI	444440	A.5
L16S4RVI	444441	A.5
L16S6FFI	444442	A.5
L16S6RVI	444443	A.5
L1CTC1	444450	A.12
L1CTC3	444451	A.12
L1LHD	444240	A.13
L1RHD	444241	A.13
L220NRC	444427	A.8
L225NRC	444429	A.8
L232NRC	444430	A.8
L240NRC	444432	A.8
L25DARC	444404	A.14
L25N4FFI	444444	A.5
L25N4RVI	444445	A.5
L25N6FFI	444446	A.5
L25N6RVI	444446	A.5
L25NCHT	444407	A.14
L25NCLS	444408	A.14
L2CTC1	444452	A.12
L2CTC3	444453	A.12
L2LHD	444242	A.13
L2RHD	444243	A.13
L40DARC	444410	A.14
L40DCHT	444411	A.14
L40DCLS	444409	A.14
LAS3	444205	A.9
LAS3R	444208	A.11
LAS4	444206	A.9
LAS4R	444209	A.11
LBAT1	444207	A.9
LBAT1R	444210	A.11
LBCA9	444214	A.9
LBPRO	444211	A.9
LBRON	444212	A.9
LCPRO	444215	A.9
LCPS1	444230	A.9
LCPS1R	444231	A.11
LCPS2	444232	A.9
LCPS2R	444233	A.11
LCRON	444216	A.9
LDPRF	444200	A.14
LFAL1	444413	A.14
LFAL2	444414	A.14
LG04N1	444012	A.4
LG04N3	444045	A.4
LG04N4	444078	A.4
LG04N6	444112	A.4
LG04S1	444000	A.4
LG04S3	444033	A.4
LG04S4	444066	A.4
LG04S6	444100	A.4
LG07N1	444013	A.4
LG07N3	444046	A.4
LG07N4	444079	A.4
LG07N6	444113	A.4
LG07S1	444001	A.4
LG07S3	444034	A.4
LG07S4	444067	A.4
LG07S6	444101	A.4
LG08N1	444014	A.4
LG08N3	444047	A.4
LG08N4	444080	A.4
LG08N6	444114	A.4
LG08S1	444002	A.4
LG08S3	444035	A.4
LG08S4	444068	A.4
LG08S6	444102	A.4
LG10N1	444015	A.4
LG10N3	444048	A.4
LG10N4	444081	A.4
LG10N6	444115	A.4
LG10S1	444003	A.4
LG10S3	444036	A.4
LG10S4	444069	A.4
LG10S6	444103	A.4
LG13N1	444016	A.4
LG13N2UR	444301	A.12
LG13N3	444049	A.4
LG13N4	444082	A.4
LG13N5UR	444304	A.12
LG13N6	444116	A.4
LG13S1	444004	A.4
LG13S2FM	444270	A.5
LG13S2FR	444300	A.12
LG13S2HM	444272	A.5
LG13S2HR	444302	A.12
LG13S2UM	444271	A.5
LG13S3	444037	A.4
LG13S4	444070	A.4
LG13S5FM	444273	A.5
LG13S5FR	444303	A.12
LG13S5HM	444275	A.5
LG13S5HR	444305	A.12
LG13S5UM	444274	A.5
LG13S6	444104	A.4
LG16N1	444017	A.4
LG16N2UR	444307	A.12
LG16N3	444050	A.4
LG16N4	444083	A.4
LG16N5UR	444310	A.12
LG16N6	444117	A.4
LG16S1	444005	A.4
LG16S2FM	444276	A.5
LG16S2FR	444306	A.12
LG16S2HM	444278	A.5
LG16S2HR	444308	A.12
LG16S2UM	444277	A.5
LG16S3	444038	A.4
LG16S4	444071	A.4
LG16S5FM	444279	A.5
LG16S5FR	444309	A.12
LG16S5HM	444281	A.5
LG16S5HR	444311	A.12
LG16S5UM	444280	A.5
LG16S6	444105	A.4
LG20C1	444008	A.4
LG20C3	444041	A.4
LG20C4	444074	A.4
LG20C6	444108	A.4
LG20D1	444020	A.4
LG20D3	444053	A.4
LG20D4	444086	A.4
LG20D6	444120	A.4
LG20N1	444018	A.4
LG20N2HM	444284	A.5
LG20N2HR	444314	A.12
LG20N3	444051	A.4
LG20N4	444084	A.4
LG20N5HM	444287	A.5
LG20N5HR	444317	A.12
LG20N6	444118	A.4
LG20S1	444006	A.4
LG20S3	444039	A.4
LG20S4	444072	A.4
LG20S6	444106	A.4
LG25C1	444009	A.4
LG25C3	444042	A.4
LG25C4	444075	A.4
LG25C6	444109	A.4
LG25D1	444021	A.4
LG25D3	444054	A.4
LG25D4	444087	A.4
LG25D6	444121	A.4
LG25N1	444019	A.4
LG25N2FM	444282	A.5
LG25N2FR	444312	A.12
LG25N2UM	444283	A.5
LG25N3	444052	A.4
LG25N4	444085	A.4
LG25N5FM	444285	A.5
LG25N5FR	444315	A.12
LG25N5UM	444286	A.5
LG25N2UR	444313	A.12
LG25N5UR	444316	A.12
LG25N6	444119	A.4
LG25S1	444007	A.4
LG25S3	444040	A.4
LG25S4	444073	A.4
LG25S6	444107	A.4
LG32C1	444010	A.4
LG32C3	444043	A.4
LG32C4	444076	A.4
LG32C6	444110	A.4
LG32D1	444022	A.4
LG32D2HM	444289	A.5
LG32D2HR	444319	A.12
LG32D2UM	444288	A.5
LG32D2UR	444318	A.12
LG32D3	444055	A.4
LG32D4	444088	A.4
LG32D5HM	444291	A.5
LG32D5HR	444321	A.12
LG32D5UM	444290	A.5
LG32D5UR	444320	A.12
LG32D6	444122	A.4
LG40C1	444011	A.4
LG40C3	444044	A.4
LG40C4	444077	A.4
LG40C6	444111	A.4
LG40D1	444023	A.4
LG40D2VM	444292	A.5
LG40D2VR	444322	A.12
LG40D3	444056	A.4
LG40D4	444089	A.4
LG40D5VM	444293	A.5
LG40D5VR	444323	A.12
LG40D6	444123	A.4
LI2FAD	444221	A.10
LI2WAD	444222	A.10
LI3FB	444223	A.10
LI3FC	444225	A.10
LI3FDT	444227	A.10
LI3WB	444224	A.10
LI3WC	444226	A.10
LI3WDT	444228	A.10
LJ04R1	444135	A.6
LJ04R3	444147	A.6
LJ04R4	444161	A.6
LJ04R6	444173	A.6
LJ07R1	444136	A.6
LJ07R3	444148	A.6
LJ07R4	444162	A.6
LJ07R6	444174	A.6
LJ08R1	444137	A.6
LJ08R3	444149	A.6
LJ08R4	444163	A.6
LJ08R6	444175	A.6
LJ10R1	444138	A.6
LJ10R3	444150	A.6
LJ10R4	444164	A.6
LJ10R6	444176	A.6
LJ13R1	444139	A.6
LJ13R3	444151	A.6
LJ13R4	444165	A.6
LJ13R6	444177	A.6
LJ16R1	444140	A.6
LJ16R3	444152	A.6
LJ16R4	444166	A.6
LJ16R6	444178	A.6
LJ20C1	444143	A.6
LJ20C3	444155	A.6
LJ20C4	444169	A.6
LJ20C6	444181	A.6
LJ20R1	444141	A.6
LJ20R3	444153	A.6
LJ20R4	444167	A.6
LJ20R6	444179	A.6
LJ25C1	444144	A.6
LJ25C3	444156	A.6
LJ25C4	444170	A.6
LJ25C6	444182	A.6
LJ25R1	444142	A.6
LJ25R3	444154	A.6
LJ25R4	444168	A.6
LJ25R6	444180	A.6
LJ32C1	444145	A.6
LJ32C3	444157	A.6
LJ32C4	444171	A.6
LJ32C6	444183	A.6
LJ40C1	444146	A.6
LJ40C3	444158	A.6
LJ40C4	444172	A.6
LJ40C6	444184	A.6
LM01024D	444190	A.9
LM01024DR	444195	A.11
LM01110D	444191	A.9
LM01110DR	444196	A.11
LM01120A	444193	A.9
LM01120AR	444198	A.11
LM01220D	444192	A.9
LM01220DR	444197	A.11
LM01240A	444194	A.9
LM01240AR	444199	A.11
LREPM	444246	A.13
LRHN	444412	A.14
LSDT	444415	A.14
LTG00K1XXSF	444260	A.8
LTG00K2XXSF	444261	A.8
LTG00K3XXS	444263	A.8
LTG00K9XXSF	444262	A.8
SMN31F16L16N	444470	A.15
SMN31F25L25N	444475	A.15
SMN31W16L16N	444490	A.15
SMN31W25L25N	444495	A.15
SMN41F16L16N	444471	A.15
SMN41F25L25N	444476	A.15
SMN41W16L16N	444491	A.15
SMN41W24L25N	444496	A.15
SMS31F16L16S	444465	A.15
SMS31W12L13S	444480	A.15
SMS41F16L16S	444466	A.15
SMS41W12L13S	444481	A.15

Notes

The policy of GE is one of continuous improvement.
The right is reserved to alter the design or any structural details of the products at any time without giving notice.

December 2013
GE Industrial Solutions

Notes

GE
Industrial Solutions

GE Industrial Solutions is a first class global supplier of low and medium voltage products including wiring devices, residential and industrial electrical distribution components, automation products, enclosures and switchboards. Demand for the company's products comes from wholesalers, installers, panelboard builders, contractors, OEMs and utilities worldwide.

www.ge.com/ex/industrialsolutions
www.ge.com/uk/industrialsolutions

Belgium
GE Industrial Belgium
Nieuwevaart 51
B-9000 Gent
Tel. +32 (0)9 265 21 11

Finland
GE Industrial Solutions
Kuortaneenkatu 2
FI-00510 Helsinki
Tel. +358 (0)10 394 3760

France
GE Industrial Solutions
Paris Nord 2
13, rue de la Perdrix
F-95958 Roissy CDG Cédex
Tel. +33 (0)800 912 816

Germany
GE Industrial Solutions
Robert-Bosch Str. 2a
D-50354 Hürth-Efferen
Tel. +49 (0) 2233/ 9719-0

Hungary
GE Hungary Kft.
Vaci ut 81-83.
H-1139 Budapest
Tel. +36 1 447 6050

Italy
GE Industrial Solutions
Centro Direzionale Colleoni
Via Paracelso 16
Palazzo Andromeda B1
I-20864 Agrate Brianza (MB)
Tel. +39 039 637 371

Netherlands
GE Industrial Solutions
Parallelweg 10
Nl-7482 CA Haaksbergen
Tel. +31 (0)53 573 03 03

Poland
GE Power Controls
Ul. Odrowaza 15
03-310 Warszawa
Tel. +48 22 519 76 00

Ul. Leszczyńska 6
43-300 Bielsko-Biała
Tel. +48 33 828 62 33

Portugal
GE Industrial Solutions
Rua Camilo Castelo Branco, 805
Apartado 2770
P-4401-601 Vila Nova de Gaia
Tel. +351 22 374 60 00

Russia
GE Industrial Solutions
27/8, Electrozavodskaya street
Moscow, 107023
Tel. +7 495 937 11 11

South Africa
GE Industrial Solutions
Unit 4, 130 Gazelle Avenue
Corporate Park Midrand 1685
P.O. Box 76672 Wendywood 2144
Tel. +27 11 238 3000

Spain
GE Industrial Solutions
P.I. Clot del Tufau, s/n
E-08295 Sant Vicenç de Castellet
Tel. +34 900 993 625

Turkey
General Elektrik Ticaret ve Servis A.S.
Sun Plaza. Maslak Mah.
Dereboyu Cad. Bilim Sok. No: 5
34398 Istanbul
Tel. +90 212 366 26 26

United Arab Emirates
GE Industrial Solutions
Injaz Building, 3rd Floor
Dubai Internet City
PO Box 11549, Dubai
Tel. +971 4 4546912

United Kingdom
GE Industrial Solutions
2 The Arena, Downshire Way
Bracknell, Berkshire.
RG12 1PU
Tel. +44 845 070 2467

GE imagination at work

680837
Ref. I/3323/E/EX 1.0 Ed.12/13

© Copyright GE Industrial Solutions 2014